Vokèra
heating for life

# Mynute 25 A

## High efficiency system boiler



**Users Instructions**

**Installation & Servicing Instructions**

CE

THESE INSTRUCTIONS
TO BE RETAINED
BY USER

benchmark
COLLECTIVE MARK
THE MARK OF QUALITY FOR THE INSTALLATION, COMMISSIONING AND SERVICING OF DOMESTIC HEATING AND HOT WATER SYSTEMS

Vokèra is a licensed member of the Benchmark scheme which aims to improve the standards of installation and commissioning of domestic hot water systems in the UK.

## Users instructions


| Things you should know | | Page |
|---|---|---|
| 1.1 | Gas appliances | 1 |
| 1.2 | Electrical supply | 1 |
| 1.3 | Guarantee registration card | 1 |
| 1.4 | Appliance Log Book (UK only) | 1 |
| 1.5 | How does it work? | 1 |
| 1.6 | Dimensions | 1 |
| 1.7 | Clearances required | 1 |
| 1.8 | Frost protection system | 1 |
| 1.9 | Appliance status indicators | 1 |

| Getting started | | Page |
|---|---|---|
| 2.1 | Before switching ON | 3 |
| 2.2 | Appliance controls | 3 |
| 2.3 | Lighting the boiler | 3 |
| 2.4 | Adjusting the heating temperature | 3 |
| 2.5 | Explanation of features | 3 |
| 2.6 | Automatic temperature control | 3 |

| How to... | | Page |
|---|---|---|
| 3.1 | How to top-up the system pressure | 3 |
| 3.2 | How to reset the appliance | 3 |
| 3.3 | How to shut down the system for short periods | 3 |
| 3.4 | How to shut down the system for long periods | 3 |
| 3.5 | How to care for the appliance | 3 |

| What if... | | Page |
|---|---|---|
| 4.1 | What if I suspect a gas leak | 4 |
| 4.2 | What if I have frequently top-up the system | 4 |
| 4.3 | What if the appliance is due its annual service | 4 |
| 4.4 | What if I need to call an engineer | 4 |


## Installation and Servicing instructions


| Design principles & operating sequence | | Page |
|---|---|---|
| 1.1 | Principle components | 6 |
| 1.2 | Mode of operation (at rest) | 6 |
| 1.3 | Mode of operation (heating) | 6 |
| 1.4 | Safety devices | 6 |

| Technical data | | Page |
|---|---|---|
| 2.1 | Central heating | 7 |
| 2.2 | Gas pressures | 7 |
| 2.3 | Expansion vessel | 7 |
| 2.4 | Dimensions | 7 |
| 2.5 | Clearances | 7 |
| 2.6 | Connections | 7 |
| 2.7 | Electrical | 7 |
| 2.8 | Flue details (concentric) | 7 |
| 2.9 | Flue details (twin pipes) | 7 |
| 2.10 | Efficiency | 7 |
| 2.11 | Emissions | 7 |
| 2.12 | Pump duty | 8 |

| General requirements (UK) | | Page |
|---|---|---|
| 3.1 | Related documents | 9 |
| 3.2 | Location of appliance | 9 |
| 3.3 | Gas supply | 9 |
| 3.4 | Flue system | 9 |
| 3.5 | Air supply | 9 |
| 3.6 | Water circulation | 9 |
| 3.7 | Electrical supply | 10 |
| 3.8 | Mounting on a combustible surface | 10 |
| 3.9 | Timber framed buildings | 10 |
| 3.10 | Inhibitors | 10 |
| 3.11 | Showers | 10 |

| General requirements (EIRE) | | Page |
|---|---|---|
| 3A.1 | Related documents | 10 |
| 3A.2 | Location of appliance | 10 |
| 3A.3 | Gas supply | 10 |
| 3A.4 | Flue system | 10 |
| 3A.5 | Air supply | 11 |
| 3A.6 | Water circulation | 11 |
| 3A.7 | Electrical supply | 11 |
| 3A.8 | Mounting on a combustible surface | 11 |
| 3A.9 | Timber framed buildings | 11 |
| 3A.10 | Inhibitors | 11 |
| 3A.11 | Showers | 11 |
| 3A.12 | Declaration of conformity | 11 |

| Installation | | Page |
|---|---|---|
| 4.1 | Delivery | 12 |
| 4.2 | Contents | 12 |
| 4.3 | Unpacking | 12 |
| 4.4 | Preparation for mounting the appliance | 12 |
| 4.5 | Fitting the flue | 12 |
| 4.6 | Connecting the gas & water | 15 |
| 4.7 | Electrical connections | 16 |

| Commissioning | | Page |
|---|---|---|
| 5.1 | Gas supply installation | 17 |
| 5.2 | The heating system | 17 |
| 5.3 | Initial filling of the system | 17 |
| 5.4 | Initial flushing of the system | 17 |
| 5.5 | Pre-operation checks | 17 |
| 5.6 | Initial lighting | 17 |
| 5.7 | Checking gas pressure & combustion analysis | 17 |
| 5.8 | Final flushing of the heating system | 17 |
| 5.9 | Setting the boiler operating temperature | 17 |
| 5.10 | Setting the system design pressure | 17 |
| 5.11 | Regulating the central heating system | 18 |
| 5.12 | Final checks | 18 |
| 5.13 | Instructing the user | 18 |

| Servicing | | Page |
|---|---|---|
| 6.1 | General | 18 |
| 6.2 | Routine annual servicing | 18 |
| 6.3 | Replacement of components | 18 |
| 6.4 | Component removal procedure | 18 |
| 6.5 | Pump assembly | 19 |
| 6.6 | Safety valve | 19 |
| 6.7 | Lower automatic air release valves | 19 |
| 6.8 | Water pressure switch | 19 |
| 6.9 | Flow thermistor | 19 |
| 6.10 | Return thermistor | 19 |
| 6.11 | Printed circuit board | 19 |
| 6.12 | Gas valve | 20 |
| 6.13 | Electrodes | 20 |
| 6.14 | Flue fan & mixer | 20 |
| 6.15 | Burner | 20 |
| 6.16 | Main heat exchanger | 21 |
| 6.17 | Automatic by-pass | 21 |
| 6.18 | Expansion vessel removal | 21 |
| 6.19 | Condense trap removal | 21 |
| 6.20 | Flue collector removal | 22 |

| Checks, adjustments and fault finding | | Page |
|---|---|---|
| 7.1 | Checking appliance operation | 23 |
| 7.2 | Appliance modes of operation | 23 |
| 7.3 | Checking the $CO_2$ & adjusting the valve | 23 |
| 7.4 | Combustion analysis test | 24 |
| 7.5 | Checking the expansion vessel | 24 |
| 7.6 | External faults | 24 |
| 7.7 | Electrical checks | 24 |
| 7.8 | Fault finding | 25 |
| 7.9 | Component values & characteristics | 25 |

| Wiring diagrams | | Page |
|---|---|---|
| 8.1 | External wiring | 26 |
| 8.2 | Typical control applications | 26 |
| 8.3 | Other devices | 26 |

| Exploded diagrams | | Page |
|---|---|---|
| 9.1 | Table 1 | 28 |
| 9.2 | Table 2 | 29 |
| 9.3 | Table 3 | 30 |
| 9.4 | Table 4 | 31 |
| 9.5 | Table 5 | 32 |

| L.P.G. instructions | | Page |
|---|---|---|
| 10.1 | Related documents | 33 |
| 10.2 | Technical data | 33 |
| 10.3 | Converting the appliance gas type | 33 |
| 10.4 | Gas supply | 33 |
| 10.5 | Gas supply installation | 33 |
| 10.6 | Checking the $CO_2$ and adjusting the gas valve | 33 |

| | Benchmark | 35-36 |
|---|---|---|

# USERS INSTRUCTIONS

## INTRODUCTION

**Dear Customer**

Your Vokèra Mynute boiler has been designed to meet and exceed the very latest standards in gas central heating technology, and if cared for, will give years of reliable use and efficiency.
Please therefore take some time to read these instructions carefully.

**Do's and Don't's**

- **Do** ensure that the system pressure is periodically checked
- **Do** ensure that the boiler should not be used by children or unassisted disabled people
- **Do** ensure that you know how to isolate the appliance in an emergency
- **Do** ensure that you are familiar with the appliance controls
- **Do** ensure that your installer has completed the appliance log book section
- **Do not** attempt to remove the appliance casing or gain internal access
- **Do not** hang clothes etc. over the appliance
- **Do not** forget to have the appliance serviced annually.

This booklet is an integral part of the appliance. It is therefore necessary to ensure that the booklet is handed to the person responsible for the property in which the appliance is located/installed. A replacement copy can be obtained from Vokèra customer services.

## 1. THINGS YOU SHOULD KNOW

### 1.1 GAS APPLIANCES

**Gas Safety (Installations and Use) Regulations (UK).**
In the interests of your safety and that of others it is a legal requirement that all gas appliances are installed and correctly maintained by a competent person and in accordance with the latest regulations.

### 1.2 ELECTRICAL SUPPLY

Please ensure that this appliance has been properly connected to the electrical supply by means of a double pole isolator or un-switched socket, and that the correct size of fuse (3 AMP) has been fitted.
**Warning: this appliance must be earthed!**

### 1.3 GUARANTEE REGISTRATION CARD

Please take the time to fill out your guarantee registration card. The completed warranty card should be posted within 30 days of installation.

### 1.4 APPLIANCE LOG BOOK (UK only)

A logbook section can be found at the rear of the appliance installation booklet. This important document must be completed during the installation/commissioning of your boiler. All GAS SAFE registered installers carry a GAS SAFE ID card, and have a registration number. These details should be recorded in the Benchmark logbook section within the installation booklet. You can check your installers details by calling GAS SAFE direct on 08004085500. Failure to install and commission the appliance in accordance with the manufacturers instructions may invalidate the warranty. This does not affect your statutory rights.

### 1.5 HOW DOES IT WORK?

Your Mynute boiler supplies heated water to your radiators and hot water to your hot water tank.
The central heating is controlled via a time clock and any thermostats that your installer may have fitted. The boiler will light when it receives a request from the time clock via any thermostat that may be installed, or whenever a hot water outlet (tap) is opened.
Your Mynute boiler lights electronically and does not have a pilot light.
In the unlikely event of a fault developing with your boiler, the supply of gas to the burner will be terminated automatically.

### 1.6 DIMENSIONS

| **Mynute 25 A** | |
|---|---|
| HEIGHT | 715 mm |
| WIDTH | 405 mm |
| DEPTH | 248 mm |

### 1.7 CLEARANCES REQUIRED

| | |
|---|---|
| ABOVE | 150 mm |
| BELOW | 150 mm |
| LEFT SIDE | 12 mm |
| RIGHT SIDE | 12 mm |
| FRONT | 600 mm |

### 1.8 FROST PROTECTION SYSTEM

The Mynute is equipped with a built-in frost protection system, this enables the boiler to over-ride the time controls – even if switched off – and operate the burner and/or pump, should the temperature drop below 5°C for the main. In particular the burner will be in ON status until the main temperature reaches 35°C for CH appliance.
Please note that the frost protection system is designed to protect the appliance only, should frost protection be required for the heating system, additional controls may be required.
**NOTE**
The frost protection system is reliant on the appliance having a permanent electrical supply, and being in a non-fault condition.

### 1.9 APPLIANCE STATUS INDICATORS

Your boiler is equipped with 3 status LED indicators, the Green LED indicates that the flame is present, the Red LED indicates the appliance has detected a fault, whilst the Yellow LED indicates that there is Servicing operation in progress.

Fig. 1




## BOILER STATUS LED

**Green LED** Boiler is working/responding to a heating/hot water request

**Red LED** Boiler has identified a fault and has failed-safe. Refer to instructions on how to reset

**Yellow LED** Service operation

## PRESSURE GAUGE

Ensure the system pressure is set correctly (minimum 0.5-bar)

## MODE SELECTOR SWITCH/HEATING TEMPERATURE SELECTOR

Mode selector switch:

**Heating & hot water** - Select this position when you want the boiler to respond to a heating and hot water request from the time-clock programmer

**Heating temperature selector**: move the selector clockwise to increase the heating outlet temperature, or counter-clockwise to reduce the temperature (range: 40°C-80°C for standard central heating).
The automatic temperature control function (SARA) is set within position 4 and 6.



**Boiler at OFF/standby** - Select this position when you want the boiler to be switched off for short periods (days) or if the boiler requires to be reset



**Pressure gauge** shows the current pressure of your heating system, the gauge should be set between 1 and 1.5 BAR. When the appliance is operating the gauge may rise or fall slightly, this is quite normal. The minimum permissible level for the safe and efficient operation of the appliance is 0.5 BAR. Should the pressure fall below 0.5 BAR, the boiler may lockout.



# 2. GETTING STARTED

## 2.1 BEFORE SWITCHING ON

Before switching the appliance on, please familiarise yourself with:
- how to isolate the appliance from the gas, water, and electricity supplies;
- how to check and top-up – if necessary – the system water pressure;
- the time clock or programmer (if fitted);
- any external thermostats and their functions;
- the appliance controls.

## 2.2 APPLIANCE CONTROLS (see fig. 1)

The appliance controls are situated on the lower front of the appliance. The appliance controls include:
- pressure gauge;
- appliance mode selector;
- temperature selector;
- burner ON mode (green);
- fault indicator (red);
- servicing mode indicator (yellow)
- optional integral time clock/programmer (if fitted).

**NOTE**
The appliance frost protection is active in all the boiler modes.
The **temperature selector** can be used to vary the temperature of the water that circulates around your radiators.
The temperature range is adjustable between 40°C and 80°C.

The **3 LED normally** shows the operating temperature of the appliance.
When the **status indicator (Green) is lit** it indicates that the flame is present and the burner is ON.
When the **fault indicator (Red) is lit** it indicates that the appliance has identified a possible fault and performed a safety lockout.
When the **fault indicator (Yellow) is lit** it indicates that there is a Servicing operation in progress.
The **integral time clock (when fitted)** can be used to switch the heating on and off at pre-determined intervals.

## 2.3 LIGHTING THE BOILER

**Ensure the gas and electrical supply to the boiler are turned on.**
Turn the mode selector switch to the **ON** position. When there is a request for heating or hot water via the time clock or programmer, the boiler will begin an ignition sequence. When the appliance reaches the CH set temperature, the burner will go off for a minimum period of approximately 3 minutes.
When the programmer/time clock or external thermostats heating request has been satisfied, the appliance will switch off automatically.

## 2.4 ADJUSTING THE HEATING TEMPERATURE

Rotate the temperature selector – clockwise to increase, counter-clockwise to decrease – to the desired temperature setting. The temperature can be set from a minimum of 40°C to a maximum of 80°C (if standard CH mode is selected).

## 2.5 EXPLANATION OF FEATURES

Although the Vokèra Mynute has been designed for simplicity of use, it utilises the latest in boiler technology, enabling a host of functions to be carried out simultaneously.

## 2.6 AUTOMATIC TEMPERATURE CONTROL

The automatic temperature control function (SARA), permits the boiler (when the heating temperature selector is set within 4 and 6 sector) to automatically adjust (raise) the heating.
The activation and the disable of the function is visualized by blinking the green led.

# 3. HOW TO...

## 3.1 HOW TO TOP-UP THE SYSTEM PRESSURE (fig. 1-2)

The system pressure must be checked periodically to ensure the correct operation of the boiler. The needle on the gauge should be reading between 1 and 1.5 BAR when the boiler is in an off position and has cooled to room temperature. If the pressure requires 'topping-up' use the following instructions as a guide.
- Locate the filling valve connections (usually beneath the boiler, see fig. 2).
- Attach the filling loop to both connections.
- Open the filling valve slowly until you hear water entering the system.
- Close the filling valve when the pressure gauge (on the boiler) reads between 1 and 1.5 BAR (see fig. 1).
- Remove the filling loop from the connections.

## 3.2 HOW TO RESET THE APPLIANCE

When the red fault LED is illuminated, the appliance will require to be reset manually. Before resetting the boiler, check what action is required to be taken, using the information on the fault code table below. Allow a period of two minutes to elapse before rotate the mode selector knob across the ⏻ position (see fig. 1).

**IMPORTANT**
If the appliance requires to be reset frequently, it may be indicative of a fault, please contact your installer or Vokèra Customer Services for further advice.

## 3.3 HOW TO SHUT DOWN THE SYSTEM FOR SHORT PERIODS

The system and boiler can be shut down for short periods by simply turning the time clock to the off position. It is also advisable to turn off the main water supply to the house.

## 3.4 HOW TO SHUT DOWN THE SYSTEM FOR LONG PERIODS

If the house is to be left unoccupied for any length of time – especially during the winter – the system should be thoroughly drained of all water. The gas, water, and electricity supply to the house should also be turned off. For more detailed advice contact your installer.

## 3.5 HOW TO CARE FOR THE APPLIANCE

To clean the outer casing use only a clean damp cloth. Do not use any scourers or abrasive cleaners.

Fig. 2



## APPLIANCE STATUS LED AND FAULT CODES

| | Alarm type | Led RED | Led YELLOW | Led GREEN | Action |
|---|---|---|---|---|---|
| Purge cycle mode active | NA | BLINKING | BLINKING | BLINKING | |
| Alarm high limit thermostat | Final | BLINKING | OFF | OFF | Reset appliance. Call engineer if fault re-occurs |
| Alarm system water pressure | Final | ON | OFF | ON | Check/refill system pressure, reset, check. Call engineer if fault re-occurs |
| Alarm safety shutdown and/or internal fault | Final | ON | OFF | OFF | Reset appliance. Call engineer if fault re-occurs |
| Temporary fault | Temporary | OFF | OFF | BLINKING | None |
| Service operation | NA | OFF | BLINKING | OFF | None |
| Flame ON | NA | OFF | OFF | ON | None |
| Fault sensors | Final | BLINKING | OFF | BLINKING | Reset appliance. Call engineer if fault re-occurs |
| Boiler stand-by | NA | OFF | OFF | BLINKING | None |

# 4. WHAT IF...

## 4.1 WHAT IF I SUSPECT A GAS LEAK

If you suspect a gas leak, turn off the gas supply at the gas meter and contact your installer or local gas supplier. If you require further advice please contact your nearest Vokèra office.

## 4.2 WHAT IF I HAVE FREQUENTLY TO TOP-UP THE SYSTEM

If the system regularly requires topping-up, it may be indicative of a leak. Please contact your installer and ask him to inspect the system.

## 4.3 WHAT IF THE APPLIANCE IS DUE ITS ANNUAL SERVICE

**Advice for tenants only**
Your landlord should arrange for servicing.

**Advice for homeowners**
Please contact Vokèra Customer Service **(0844 3910999 (UK) or 056 7755057 (ROI)** if you would prefer a Vokèra service engineer or agent to service your appliance. Alternatively your local GAS SAFE registered engineer may be able to service the appliance for you.

## 4.4 - WHAT IF I NEED TO CALL AN ENGINEER

If you think your boiler may have developed a fault, please contact your installer or Vokèra Customer Services **(0844 3910999 (UK) or 056 7755057 (ROI)** have all your details to hand including full address and postcode, relevant contact numbers, and your completed appliance log book.

Fig. 3

## INTRODUCTION

The Mynute comprises a range of high-efficiency combination boilers with outputs of 25kW. These appliances – by design – incorporate electronic ignition, circulating pump, expansion vessel, safety valve, pressure gauge and automatic by-pass.
The Mynute range is produced as room sealed, category II2H3P appliances, suitable for internal wall mounting applications only. Each appliance is provided with a fan powered flue outlet with an annular co-axial combustion air intake that can be rotated – horizontally – through 360 degrees for various horizontal or vertical applications. The Mynute can also be used with the Vokèra twin flue system.
The Mynute is approved for use with C13 & C33 type flue applications.
These appliances are designed for use with a sealed system only; consequently they are not intended for use on open vented systems.
This booklet is an integral part of the appliance. It is therefore necessary to ensure that the booklet is handed to the person responsible for the property in which the appliance is located/ installed. A replacement copy can be obtained from Vokèra customer services.




Fig. 4

**General layout**

1 Drain valve
2 Safety valve
3 Pump
4 Bottom auto air vent (AAV)
5 Main heat exchanger
6 Flues thermistor (NTC)
7 Fan assembly with mixer
8 Silencer
9 Flue gas analysis test point
10 Flue outlet & air intake
11 Top AAV
12 De-aerator
13 Spark Electrode - Sensing Electrode
14 Ignition transformer
15 Flow thermistor (NTC) - High limit thermostat
16 Expansion vessel
17 Pressure switch
18 Return thermistor (NTC)
19 Gas valve
20 Condense trap

R Heating return connection
F Heating flow connection
G Gas connection

# SECTION 1 - DESIGN PRINCIPLES AND OPERATING SEQUENCE

## 1.1 PRINCIPLE COMPONENTS

- A fully integrated electronic control board featuring electronic temperature control, anti-cycle control, pump over-run, self-diagnostic fault indicator, full air/gas modulation
- Aluminium heat exchanger
- Electronic ignition with flame supervision
- Integral high-head pump
- Fan
- Expansion vessel
- Water pressure switch
- Flue sensor
- Pressure gauge
- Safety valve

## 1.2 MODE OF OPERATION (at rest)

When the appliance is at rest and there are no requests for heating or hot water, the following functions are active:

- frost-protection system – the frost-protection system protects the appliance against the risk of frost damage. For CH line, if the main temperature falls to 5°C, the appliance will function on minimum power until the temperature on main reaches 35°C.
- anti-block function – the anti-block function enables the pump to be energised for short periods, when the appliance has been inactive for more than 24-hours.

## 1.3 MODE OF OPERATION (Heating)

When there is a request for heat via the time clock and/or any external control, the pump and fan are started, the fan speed will modulate until the correct signal voltage is received at the control PCB. At this point an ignition sequence is enabled.
Ignition is sensed by the electronic circuit to ensure flame stability at the burner. Once successful ignition has been achieved, the electronic circuitry increases the gas rate to 75% for a period of 15 minutes. Thereafter, the boiler's output will either be increase to maximum or modulate to suit the set requirement. When the appliance reaches the desired temperature the burner will shut down and the boiler will perform a three-minute anti-cycle (timer delay).
When the request for heat has been satisfied the appliance pump and fan may continue to operate to dissipate any residual heat within the appliance.

## 1.4 SAFETY DEVICES

When the appliance is in use, safe operation is ensured by:

- a water pressure switch that monitors system water pressure and will de-activate the pump, fan, and burner should the system water pressure drop below the rated tolerance;
- fan speed sensor to ensure safe operation of the burner;
- a high limit thermostat that over-rides the temperature control circuit to prevent or interrupt the operation of the burner;
- flame sensor that will shut down the burner when no flame signal is detected;
- flue sensor;
- a safety valve which releases excess pressure from the primary circuit.



Fig. 5

# SECTION 2 - TECHNICAL DATA

| | |
|---|---|
| **2.1 Central Heating** | |
| Heat input (kW) | 25.00 |
| Maximum heat output (kW) 60/80°C | 24.40 |
| Minimum working pressure | 0.5 bar |
| Maximum working pressure | 2.7 bar |
| **2.2 Gas Pressures** | |
| Inlet pressure (G20) | 20.0 mbar |
| Heating maximum gas rate ($m^3$/hr) | 2.64 |
| Minimum gas rate ($m^3$/hr) | 0.63 |
| Injector size (mm) | 5.7 |
| Silencer flange (ø mm) (fitted) | 31 |
| **2.3 Expansion Vessel** | |
| Capacity | 8 litres |
| Maximum system volume | 74 litres |
| Pre-charge pressure | 1 bar |
| **2.4 Dimensions** | |
| Height (mm) | 715 |
| Width (mm) | 405 |
| Depth (mm) | 248 |
| Dry weight (kg) | 32 |
| **2.5 Clearances** | |
| Sides | 12mm |
| Top | 150mm from casing or 25mm above flue elbow (whichever is applicable) |
| Bottom | 150mm |
| Front | 500mm |
| **2.6 Connections** | |
| Flow & return | 22mm |
| Gas | 15mm |
| Safety valve | 15mm |
| Condense | 21mm |
| **2.7 Electrical** | |
| Power consumption (Watts) | 140W |
| Voltage (V/Hz) | 230/50 |
| Internal fuse | 3.15A T (for PCB) - 3.15A F (for connections block) |
| External fuse | 3A |
| **2.8 Flue Details (concentric)** | |
| Maximum horizontal flue length (60/100mm) | 4.0m |
| Maximum vertical flue length (60/100mm) | 5.0m |
| **2.9 Flue Details (twin pipes)** | |
| Maximum horizontal flue length (80mm/80mm) | 20m/20m |
| Maximum vertical flue length (80mm/80mm) | 20m/20m |
| **2.10 Efficiency** | |
| **SEDBUK (%)** | 90.1 |
| **2.11 Emissions** | |
| $CO_2$ @ maximum output (%) | 9.0 |
| $CO_2$ @ minimum output (%) | 9.5 |
| CO @ maximum output (ppm) | 160 |
| CO @ minimum output (ppm) | 35 |
| NOx rating | class 5 |

## 2.12 PUMP DUTY

Fig. 6 shows the flow-rate available – after allowing for pressure loss through the appliance – for system requirements. When using this graph, apply only the pressure loss of the system. The graph is based on a 20°C temperature differential.




Fig. 6

Fig. 7




| Key | Location | Minimum distance |
|---|---|---|
| A | Below an opening (window, air-brick, etc.) | 300 mm |
| B | Above an opening (window, air-brick, etc.) | 300 mm |
| C | To the side of an opening (window, air-brick, etc.) | 300 mm |
| D | Below gutter, drain-pipe, etc. | 25 mm |
| E | Below eaves | 25 mm |
| F | Below balcony, car-port roof, etc. | 25 mm |
| G | To the side of a soil/drain-pipe, etc. | 25 mm (60mm for 80/125 - 5" flue) |
| H | From internal/external corner | 25 mm (60mm for 80/125 - 5" flue) |
| I | Above ground, roof, or balcony level | 300 mm |
| J | From a surface or boundary facing the terminal | 600 mm |
| K | From a terminal facing a terminal | 1200 mm |
| L | From an opening in the car-port into the building | 1200 mm |
| M | Vertically from a terminal on the same wall | 1500 mm |
| N | Horizontally from a terminal on the same wall | 300 mm |
| P | From a structure to the side of the vertical terminal | 300 mm |
| Q | From the top of the vertical terminal to the roof flashing | As determined by the fixed collar of the vertical terminal |
| R | To the side of a boundary | 300 mm |
| S | To the side of an opening or window on a pitched roof | 600 mm |
| T | Below an opening or window on a pitched roof | 2000 mm |
| V | From a vertical terminal to an adjacent opening (window, air-brick, etc.) | (call Vokera technical for advice) |
| W | From a vertical terminal to an adjacent vertical terminal | 300 mm (only if both terminals are the same hight) |

# SECTION 3 - GENERAL REQUIREMENTS (UK)

This appliance must be installed by a competent person in accordance with the Gas Safety (Installation & Use) Regulations.

## 3.1 RELATED DOCUMENTS

The installation of this boiler must be in accordance with the relevant requirements of the Gas Safety (Installation & Use) Regulations, the local building regulations, the current I.E.E. wiring regulations, the bylaws of the local water undertaking, the Building Standards (Scotland) Regulation and Building Standards (Northern Ireland) Regulations.
It should be in accordance also with any relevant requirements of the local authority and the relevant recommendations of the following British Standard Codes of Practice.

## 3.2 LOCATION OF APPLIANCE

The appliance may be installed in any room or internal space, although particular attention is drawn to the requirements of the current I.E.E. wiring regulations, and in Scotland, the electrical provisions of the Building Regulations, with respect to the installation of the appliance in a room or internal space containing a bath or shower.
When an appliance is installed in a room or internal space containing a bath or shower, the appliance or any control pertaining to it must not be within reach of a person using the bath or shower. The location chosen for the appliance must permit the provision of a safe and satisfactory flue and termination. The location must also permit an adequate air supply for combustion purposes and an adequate space for servicing and air circulation around the appliance. Where the installation of the appliance will be in an unusual location special procedures may be necessary, BS 6798 gives detailed guidance on this aspect. A compartment used to enclose the appliance must be designed and constructed specifically for this purpose. An existing compartment/cupboard may be utilised provided that it is modified to suit. Details of essential features of compartment/cupboard design including airing cupboard installations are given in BS 6798. This appliance is not suitable for external installation.

## 3.3 GAS SUPPLY

The gas meter – as supplied by the gas supplier – must be checked to ensure that it is of adequate size to deal with the maximum rated input of all the appliances that it serves. Installation pipes must be fitted in accordance with BS 6891. Pipe work from the meter to the appliance must be of adequate size. Pipes of a smaller size than the appliance gas inlet connection must not be used. The installation must be tested for tightness in accordance with BS6891.
If the gas supply serves more than one appliance, it must be ensured that an adequate supply is maintained to each appliance when they are in use at the same time.

## 3.4 FLUE SYSTEM

The terminal should be located where the dispersal of combustion products is not impeded and with due regard for the damage and discoloration that may occur to building products located nearby. The terminal must not be located in a place where it is likely to cause a nuisance (see fig. 7). In cold and/or humid weather, water vapour will condense on leaving the terminal; the effect of such pluming must be considered.
If installed less than 2m above a pavement or platform to which people have access (including balconies or flat roofs) the terminal must be protected by a guard of durable material. The guard must be fitted centrally over the terminal. Refer to BS 5440 Part 1, when the terminal is 0.5 metres (or less) below plastic guttering or 1 metre (or less) below painted eaves.

## 3.5 AIR SUPPLY

The following notes are intended for general guidance only. This appliance is a room-sealed, fan-flued boiler, consequently it does not require a permanent air vent for combustion air supply. When installed in a cupboard or compartment, ventilation for cooling purposes is also not required.

## 3.6 WATER CIRCULATION

Detailed recommendations are given in BS 5449 Part 1 and BS 6798. The following notes are for general guidance only.

### 3.6.1 PIPEWORK

It is recommended that copper tubing to BS 2871 Part 1 is used in conjunction with soldered capillary joints. Where possible pipes should have a gradient to ensure air is carried naturally to air release points and that water flows naturally to drain cocks. Except where providing useful heat, pipes should be insulated to avoid heat loss and in particular to avoid the possibility of freezing. Particular attention should be paid to pipes passing through ventilated areas such as under floors, loft space and void areas.

| | | |
|---|---|---|
| **BS 5440** | **PART 1** | **FLUES** |
| **BS 5440** | **PART 2** | **FLUES & VENTILATION** |
| **BS 5449** | **PART 1** | **FORCED CIRCULATION HOT WATER SYSTEMS** |
| **BS 5546** | | **INSTALLATION OF GAS HOT WATER SUPPLIES FOR DOMESTIC PURPOSES** |
| **BS 6798** | | **INSTALLATION OF BOILERS OF RATED INPUT NOT EXCEEDING 60kW** |
| **BS 6891** | | **LOW PRESSURE INSTALLATION PIPES** |
| **BS 7074** | **PART 1** | **APPLICATION, SELECTION, AND INSTALLTION OF EXPANSION VESSELS AND ANCILLARY EQUIPMENT FOR SEALED WATER SYSTEMS** |

### 3.6.2 AUTOMATIC BY-PASS

The appliance has a built-in automatic by-pass, consequently there is no requirement for an external by-pass, however the design of the system should be such that it prevents boiler 'cycling'.

### 3.6.3 DRAIN COCKS

These must be located in accessible positions to facilitate draining of the appliance and all water pipes connected to the appliance. The drain cocks must be manufactured in accordance with BS 2879.

### 3.6.4 AIR RELEASE POINTS

These must be positioned at the highest points in the system where air is likely to be trapped. They should be used to expel trapped air and allow complete filling of the system.

### 3.6.5 EXPANSION VESSEL

The appliance has an integral expansion vessel to accommodate the increased volume of water when the system is heated. It can accept up to 8 litres of expansion from within the system, generally this is sufficient, however if the system has an unusually high water content, it may be necessary to provide additional expansion capacity (see 6.18).

### 3.6.6 FILLING POINT

A method for initial filling of the system and replacing water lost during servicing etc. directly from the mains supply, is provided (see fig. 8). This method of filling complies with the current Water Supply (Water Fittings) Regulations 1999 and Water Bylaws 2000 (Scotland). If an alternative location is preferred, it should be connected as detailed in fig. 8.

### 3.6.7 LOW PRESSURE SEALED SYSTEM

An alternative method of filling the system would be from an independent make-up vessel or tank mounted in a position at least 1 metre above the highest point in the system and at least 5 metres above the boiler (see fig. 9).
The cold feed from the make-up vessel or tank must be fitted

with an approved non-return valve and stopcock for isolation purposes. The feed pipe should be connected to the return pipe as close to the boiler as possible.

**3.6.8 FREQUENT FILLING**

Frequent filling or venting of the system may be indicative of a leak. Care should be taken during the installation of the appliance to ensure all aspects of the system are capable of withstanding pressures up to at least 3 bar.

## 3.7 ELECTRICAL SUPPLY

The appliance is supplied for operation on 230V @ 50Hz electrical supply; it must be protected with a 3-amp fuse. The method of connection to the mains electricity supply must allow for complete isolation from the supply. The preferred method is by using a double-pole switch with a contact separation of at least 3,5mm (3° high-voltage category). The switch must only supply the appliance and its corresponding controls, i.e. time clock, room thermostat, etc. Alternatively an un-switched shuttered socket with a fused 3-pin plug both complying with BS 1363 is acceptable.

## 3.8 MOUNTING ON A COMBUSTIBLE SURFACE

If the appliance is to be fitted on a wall of combustible material, a sheet of fireproof material must protect the wall.

## 3.9 TIMBER FRAMED BUILDINGS

If the appliance is to be fitted in a timber framed building, it should be fitted in accordance with the Institute of Gas Engineers publication (IGE/UP/7) 'Guide for Gas Installations in Timber Frame Buildings'.

## 3.10 INHIBITORS

Vokèra recommend that an inhibitor - suitable for use with aluminium heat exchangers - is used to protect the boiler and system from the effects of corrosion and/or electrolytic action. The inhibitor must be administered in strict accordance with the manufacturers instructions*.

*Water treatment of the complete heating system - including the boiler - should be carried out in accordance with BS 7593 and the Domestic Water Treatment Association's (DWTA) code of practice.

## 3.11 SHOWERS

If the appliance is intended for use with a shower, the shower must be thermostatically controlled and be suitable for use with a combination boiler.



Fig. 8



Fig. 9

# SECTION 3A - GENERAL REQUIREMENTS (EIRE)

This appliance must be installed by a competent person in accordance with and defined by, the Standard Specification (Domestic Gas Installations) Declaration (I.S. 813).

## 3A.1 RELATED DOCUMENTS

The installation of this boiler must be in accordance with the relevant requirements of the local building regulations, the current ETCI National Rules for Electrical Installations and the bylaws of the local water undertaking.

It should be in accordance also with any relevant requirements of the local and/or district authority.

## 3A.2 LOCATION OF APPLIANCE

The appliance may be installed in any room or internal space, although particular attention is drawn to the requirements of the current ETCI National Rules for Electrical Installations, and I.S. 813, Annex K.

When an appliance is installed in a room or internal space containing a bath or shower, the appliance or any control pertaining to it must not be within reach of a person using the bath or shower.

The location chosen for the appliance must permit the provision of a safe and satisfactory flue and termination. The location must also permit an adequate air supply for combustion purposes and an adequate space for servicing and air circulation around the appliance. Where the installation of the appliance will be in an unusual location special procedures may be necessary, refer to I.S. 813 for detailed guidance on this aspect.

A compartment used to enclose the appliance must be designed and constructed specifically for this purpose. An existing compartment/cupboard may be utilised provided that it is modified to suit.

This appliance is not suitable for external installation.

## 3A.3 GAS SUPPLY

The gas meter – as supplied by the gas supplier – must be checked to ensure that it is of adequate size to deal with the maximum rated input of all the appliances that it serves. Installation pipes must be fitted in accordance with I.S. 813.

Pipe work from the meter to the appliance must be of adequate size. Pipes of a smaller size than the appliance gas inlet connection must not be used. The installation must be tested for tightness in accordance with I.S. 813.

If the gas supply serves more than one appliance, it must be ensured that an adequate supply is maintained to each appliance when they are in use at the same time.

## 3A.4 FLUE SYSTEM

The terminal should be located where the dispersal of combustion products is not impeded and with due regard for the damage and discoloration that may occur to building products located nearby. The terminal must not be located in a place where it is likely to cause a nuisance (see I.S. 813).

In cold and/or humid weather, water vapour will condense on leaving the terminal; the effect of such pluming must be considered.

If installed less than 2m above a pavement or platform to which people have access (including balconies or flat roofs) the

terminal must be protected by a guard of durable material. The guard must be fitted centrally over the terminal. Refer to I.S. 813, when the terminal is 0.5 metres (or less) below plastic guttering or 1 metre (or less) below painted eaves.

## 3A.5 AIR SUPPLY

The following notes are intended for general guidance only.
This appliance is a room-sealed, fan-flued boiler, consequently it does not require a permanent air vent for combustion air supply.
When installed in a cupboard or compartment, ventilation for cooling purposes is also not required.

## 3A.6 WATER CIRCULATION

Specific recommendations are given in I.S. 813. The following notes are for general guidance only.

### 3A.6.1 PIPEWORK

It is recommended that copper tubing be used in conjunction with soldered capillary joints.
Where possible pipes should have a gradient to ensure air is carried naturally to air release points and that water flows naturally to drain cocks.
Except where providing useful heat, pipes should be insulated to avoid heat loss and in particular to avoid the possibility of freezing. Particular attention should be paid to pipes passing through ventilated areas such as under floors, loft space and void areas.

### 3A.6.2 AUTOMATIC BY-PASS

The appliance has a built-in automatic by-pass, consequently there is no requirement for an external by-pass, however the design of the system should be such that it prevents boiler 'cycling'.

### 3A.6.3 DRAIN COCKS

These must be located in accessible positions to facilitate draining of the appliance and all water pipes connected to the appliance.

### 3A.6.4 AIR RELEASE POINTS

These must be positioned at the highest points in the system where air is likely to be trapped. They should be used to expel trapped air and allow complete filling of the system.

### 3A.6.5 EXPANSION VESSEL

The appliance has an integral expansion vessel to accommodate the increased volume of water when the system is heated. It can accept up to 8 litres of expansion from within the system, generally this is sufficient, however if the system has an unusually high water content, it may be necessary to provide additional expansion capacity (see 6.18).

### 3A.6.6 FILLING POINT

A method for initial filling of the system and replacing water lost during servicing etc. is provided (see fig. 8). You should ensure this method of filling complies with the local water authority regulations.

### 3A.6.7 LOW PRESSURE SEALED SYSTEM

An alternative method of filling the system would be from an independent make-up vessel or tank mounted in a position at least 1 metre above the highest point in the system and at least 5 metres above the boiler (see fig. 9). The cold feed from the make-up vessel or tank must be fitted with an approved non-return valve and stopcock for isolation purposes. The feed pipe should be connected to the return pipe as close to the boiler as possible.

### 3A.6.8 FREQUENT FILLING

Frequent filling or venting of the system may be indicative of a leak. Care should be taken during the installation of the appliance to ensure all aspects of the system are capable of withstanding pressures up to at least 3 bar.

## 3A.7 ELECTRICAL SUPPLY

The appliance is supplied for operation on 230V @ 50Hz electrical supply; it must be protected with a 3-amp fuse. The method of connection to the mains electricity supply must allow for complete isolation from the supply. The preferred method is by using a double-pole switch with a contact separation of at least 3,5 mm (3° high-voltage category). The switch must only supply the appliance and its corresponding controls, i.e. time clock, room thermostat, etc.

## 3A.8 MOUNTING ON A COMBUSTIBLE SURFACE

If the appliance is to be fitted on a wall of combustible material, a sheet of fireproof material must protect the wall.

## 3A.9 TIMBER FRAMED BUILDINGS

If the appliance is to be fitted in a timber framed building, it should be fitted in accordance with I.S. 813 and local Building Regulations.
The Institute of Gas Engineers publication (IGE/UP/7) 'Guide for Gas Installations in Timber Frame Buildings' gives specific advice on this type of installation.

## 3A.10 INHIBITORS

Vokèra recommend that an inhibitor - suitable for use with aluminium heat exchangers - is used to protect the boiler and system from the effects of corrosion and/or electrolytic action. The inhibitor must be administered in strict accordance with the manufacturers instructions*.
*Water treatment of the complete heating system - including the boiler - should be carried out in accordance with I.S. 813 and the Domestic Water Treatment Association's (DWTA) code of practice.

## 3A.11 SHOWERS

If the appliance is intended for use with a shower, the shower must be thermostatically controlled and be suitable for use with a combination boiler.

## 3A.12 DECLARATION OF CONFORMITY

A Declaration of Conformity (as defined in I.S. 813) must be provided on completion of the installation.
A copy of the declaration must be given to the responsible person and also to the gas supplier if required.

# SECTION 4 - INSTALLATION

## 4.1 DELIVERY

Due to the weight of the appliance it may be necessary for two people to lift and attach the appliance to its mounting. The appliance is contained within a heavy-duty cardboard carton. Lay the carton on the floor with the writing the correct way up.

## 4.2 CONTENTS

Contained within the carton is:
- the boiler
- the wall bracket
- carton template
- an accessories pack containing appliance service connections and washers
- the instruction pack containing the installation, servicing & user instructions, guarantee registration card and a 3-amp fuse.

## 4.3 UNPACKING

At the top of the carton pull both sides open – do not use a knife – unfold the rest of the carton from around the appliance, carefully remove all protective packaging from the appliance and lay the accessories etc. to one side. Protective gloves should be used to lift the appliance, the appliance back-frame should be used for lifting points.

## 4.4 PREPARATION FOR MOUNTING THE APPLIANCE

The appliance should be mounted on a smooth, vertical, non-combustible surface, which must be capable of supporting the full weight of the appliance. Care should be exercised when determining the position of the appliance with respect to hidden obstructions such as pipes, cables, etc.
When the position of the appliance has been decided – using the template supplied – carefully mark the position of the wall-mounting bracket (see fig. 10) and flue-hole (if applicable).

## 4.5 FITTING THE FLUE

The top flue outlet permits both horizontal and vertical flue applications to be considered, alternatively, the Vokèra twin flue system can be utilised if longer flue runs are required.

### 4.5.1 CONCENTRIC HORIZONTAL FLUE

(For concentric vertical flue, see 4.5.2).
(For twin flue applications, see 4.5.3).
The appliance can be used with Vokèra condensing 60/100mm concentric flue system.

**NOTE**
These instructions relate **only** to the Vokèra condensing 60/100mm concentric flue system.
The appliance flue outlet elbow can be rotated through 360º on its vertical axis. In addition the flue may be extended from the outlet elbow in the horizontal plane (see 2.9). A reduction must also be made to the maximum length (see table below) when additional bends are used.

Reduction for additional bends

| Bend | Reduction in maximum flue length for each bend |
|---|---|
| 45º bend | 0.5 metre |
| 90º bend | 1.0 metre |

Horizontal flue terminals and accessories

| Part No. | Description | Length |
|---|---|---|
| 29450120 | Horizontal flue kit | 900mm |
| 29450121 | Telescopic flue kit | 350/530mm |
| 522 | Plume management kit | 1370mm |
| 29450123 | 90-degree bend | N/A |
| 29450124 | 45-degree bends (pair) | N/A |
| 29450125 | 500mm extension | 500mm |
| 29450126 | 1000mm extension | 1000mm |
| 29450127 | 2000m extension | 2000mm |
| 29450128 | Telescopic extension | 350/730mm |
| 529 | Wall bracket pack (5) | 208mm |

Using the template provided (**A**), mark and drill a 125mm hole for the passage of the flue pipe. The hole should be drilled to ensure any condense fluid that forms, is allowed to drain back to the appliance (see fig. 12). The fixing holes for the wall-mounting bracket should now be drilled and plugged, an appropriate type and quantity of fixing should be used to ensure that the bracket is mounted securely. Once the bracket has been secured to the wall, mount the appliance onto the bracket.



Fig. 10



Fig. 11

**FITTING THE TELESCOPIC HORIZONTAL FLUE KIT**
In some instances It may necessary to cut the inner 60mm pipe of the flue bend at the point indicated (fig.13 pos. A) to allow for easier insertion to the boiler flue spigot.

**FITTING THE HORIZONTAL FLUE KIT**
Carefully measure the distance from the centre of the appliance flue outlet to the edge of the finished outside wall (dimension X). Add 65mm to dimension X to give you Dimension Y (see fig 12). Measure dimension Y from the terminal end of the concentric flue pipe and cut off the excess ensuring any burrs are removed. Pass the concentric flue pipe through the previously drilled hole. Fit the flue bend to the boiler flue outlet and insert the concentric flue pipe into the flue bend ensuring the correct seal is made. Using the clamp, gasket, and screws supplied, secure the flue bend to the appliance flue spigot.

**NOTE**
Fit the internal (white) trim to the flue assembly prior to connecting the flue pipe to the bend.
You must ensure that the entire flue system is properly supported and connected. Seal the flue assembly to the wall using cement or a suitable alternative that will provide satisfactory weather-proofing. The exterior trim can now be fitted.



Fig. 12



Fig.13

**EXTENDING THE FLUE**

Connect the bend – supplied with the terminal kit – to the top of the boiler using clamp (supplied) see fig. 11. The additional bends & extensions have push-fit connections, care should be taken to ensure that the correct seal is made when assembling the flue system. Connect the required number of flue extensions or bends (up to the maximum equivalent flue length) to the flue terminal (see fig. 11-14). The flue system should have a minimum of 1°; maximum of 3° rise from the boiler to outside, to ensure any condense fluid that forms, is allowed to drain back to the appliance.

**NOTE**

When cutting an extension to the required length, you must ensure that the excess is cut from the plain end of the extension (see fig. 11-14). Remove any burrs, and check that all seals are located properly. You must ensure that the entire flue system is properly supported and connected. Seal the flue assembly to the wall using cement or a suitable alternative that will provide satisfactory weatherproofing. The interior and exterior trim can now be fitted.


Fig. 10

**4.5.2 CONCENTRIC VERTICAL FLUE**

The appliance can be used with either the Vokèra condensing 60/100mm concentric flue system.

**NOTE**

These instructions relate **only** to the Vokèra condensing 60/100mm concentric flue system.

The vertical flue terminal can be connected directly to the appliance flue outlet. Alternatively, an extension or bend can be connected to the appliance flue outlet if desired, however if additional bends are fitted, a reduction must be made to the maximum flue length (see table below).

Reduction for bends

| Bend | Reduction in maximum flue length for each bend |
|---|---|
| 45° bend | 0.5 metre |
| 90° bend | 1.0 metre |

Vertical flue terminal and accessories

| Part No. | Description | Length |
|---|---|---|
| 29450122 | Vertical flue terminal | 1000mm |
| 531 | Pitched roof flashing plate | N/A |
| 532 | Flat roof flashing plate | N/A |
| 29450123 | 90-degree bend | N/A |
| 29450124 | 45-degree bends (pair) | N/A |
| 29450125 | 500mm extension | 500mm |
| 29450126 | 1000mm extension | 1000mm |
| 29450127 | 2000mm extension | 2000mm |
| 29450128 | Telescopic extension | 350/730mm |
| 529 | Wall bracket pack (5) | 208mm |

Using the dimensions given in fig. 12 as a reference, mark and cut a 125mm hole in the ceiling and/or roof.



Fig. 15

Fit the appropriate flashing plate to the roof and insert the vertical flue terminal through the flashing plate from the outside, ensuring that the collar on the flue terminal fits over the flashing. The fixing holes for the wall-mounting bracket should now be drilled and plugged, an 'appropriate type and quantity of fixing should be used to ensure that the bracket is mounted securely. Once the bracket has been secured to the wall, mount the appliance onto the bracket.

**IMPORTANT**
The vertical flue terminal is 1.0 metre in length and cannot be cut; therefore it may be necessary to adjust the height of the appliance to suit or use a suitable extension.
Connect the vertical flue assembly to the boiler flue spigot using the 100mm clip, gasket & screws (supplied), ensuring the correct seal is made. The flue support bracket (supplied with the vertical flue kit) can now be fitted.
If the vertical flue requires extension/s or additional bend/s, connect the required number of flue extensions or bends (up to the maximum equivalent flue length) between the boiler and vertical flue assembly (see fig. 14).
Ensure that any horizontal sections of the flue system have a minimum 1°; maximum 3° fall back to the boiler (1° = 17mm per 1000mm).

**NOTE**
When cutting an extension to the required length, you must ensure that the excess is cut from the plain end of the extension. Remove any burrs, and check that any seals are located properly.
You must ensure that the entire flue system is properly supported and connected.

**4.5.3 TWIN FLUE SYSTEM**
The Vokèra twin flue system enables greater flue distances to be achieved than that of a concentric flue system. It can be used for horizontal or vertical applications, however the twin flue system must be converted to the dedicated concentric flue kit for termination. It is essential that the installation of the twin flue system be carried out in strict accordance with these instructions.

**GUIDANCE NOTES ON TWIN FLUE INSTALLATION**
- The flue must have a have a minimum 1°; maximum 3° (1° = 17mm per 1000mm) fall back to the appliance to allow any condensate that may form in the flue system to drain via the condensate drain. Consideration must also be given to the fact that there is the possibility of a small amount of condensate dripping from the terminal.
- Ensure that the entire flue system is adequately supported, use at least one bracket for each extension.
- The entire flue system must be adequately insulated to maintain heat within the flue system thereby reducing the possibility of condensate production.
- As the exhaust outlet pipe can reach very high temperatures it must be protected to prevent persons touching the hot surface.
- The condensate drain pipe must be connected in accordance with building regulations.

Reduction for bends

| Bend | Reduction in maximum flue length for each bend |
|---|---|
| 45° bend | 1.0 metre |
| 90° bend | 1.0 metre |

Twin flue accessories

| Part No. | Description | Length |
|---|---|---|
| 0225805 | Horizontal flue terminal | 1.0 metre |
| 0225810 | Vertical flue terminal | 1.0 metre |
| 359 | Twin adapter kit | N/A |
| 531 | Pitched roof flashing plate | N/A |
| 532 | Flat roof flashing plate | N/A |
| 0225815 | Condensate drain kit | N/A |
| 0225820 | 0.25m extension (pair) | 250mm |
| 0225825 | 0.5m extension (pair) | 500mm |
| 0225830 | 1.0m extension (pair) | 1000mm |
| 0225835 | 2.0m extension (pair) | 2000mm |
| 0225840 | 45° bend (pair) | N/A |
| 0225845 | 90° bend (pair) | N/A |
| 0225850 | Twin bracket (5) | N/A |
| 0225855 | Single bracket (5) | N/A |

**MOUNTING THE BOILER**
The fixing holes for the wall-mounting bracket should now be drilled and plugged, an appropriate type and quantity of fixing should be used to ensure that the bracket is mounted securely.
Once the bracket has been secured to the wall, mount the appliance onto the bracket.

**INSTALLATION OF TWIN ADAPTOR KIT (fig. 12 & 13)**
- Insert the exhaust connection manifold (A) onto the appliance flue outlet.
- Remove the blanking plate (located to the left of the appliance flue outlet) and – using the same screws – install the air inlet plate (B).
- Using the hole in the exhaust connection manifold as a guide, drill a 3mm hole in the appliance flue spigot and secure the exhaust manifold connection to the flue spigot using the screw provided (C).
- Using the two holes in the air inlet plate as a guide, drill a 3mm hole in each and secure the air inlet pipe/bend using the screws provided.

The twin flue pipes extensions and accessories can now be installed by pushing together (the plain end of each extension or bend should be pushed approximately 50mm into the female socket of the previous piece).



Fig. 12


Fig. 13

**HORIZONTAL TERMINATION (fig. 14)**
The twin flue system must be converted to the dedicated concentric flue kit for termination.
- The horizontal terminal is supplied with a built-in converter box and cannot be shortened.
- A 130mm hole is required for the passage of the concentric terminal through the wall.
- The air inlet pipe must always be level with or below, that of the exhaust pipe.

Depending on site conditions it may be preferable to install the terminal assembly prior to fitting the twin flue pipes.

Mark and drill a level 130mm hole for the passage of the horizontal flue terminal. Insert the terminal assembly into the flue hole.
Push-fit the twin flue pipes onto the concentric to twin converter box ensuring that the exhaust pipe connects to the exhaust connection on the concentric to twin converter.
If necessary cut the plain ends (male) of the twin flue pipes to allow connection to the concentric to twin converter.

**NOTE**
Before cutting twin flue pipes ensure allowances have been made for connection onto the previous piece and onto the concentric to twin converter. The last twin flue pipes must be

pushed 50mm onto the male spigots of the concentric to twin converter.

**NOTE**
Seal the flue terminal assembly to the wall using cement or a suitable alternative that will provide satisfactory weatherproofing. The interior and exterior trim can now be fitted.

**VERTICAL TERMINATION (fig. 15)**
The twin flue system must be converted to the dedicated concentric flue kit for termination.
- The vertical terminal is supplied with a built-in converter box and cannot be shortened.
- A 130mm hole is required for the passage of the concentric terminal through the ceiling and/or roof.

Depending on site conditions it may be preferable to install the terminal assembly prior to fitting the twin flue pipes.
Fit the appropriate flashing plate to the roof and insert the vertical flue terminal through the flashing plate from the outside, ensuring that the collar on the flue terminal fits over the flashing.
Push-fit the twin flue pipes onto the concentric to twin converter ensuring that the exhaust pipe connects to the exhaust connection on the concentric to twin converter.
If necessary cut the plain ends (male) of the twin flue pipes to allow connection to the concentric to twin converter.

**NOTE**
- Before cutting twin flue pipes ensure allowances have been made for connection onto the previous piece and onto the concentric to twin converter. The last twin flue pipes must be pushed 50mm onto the male spigots of the concentric to twin converter.
- You must ensure that the entire flue system is properly supported and connected.
- Ensure that any horizontal sections of pipe have a 1° fall towards the appliance (17mm per 1000mm).



Fig. 14

## 4.6 CONNECTING THE GAS AND WATER

The appliance is supplied with an accessory pack that includes service valves.
The service valves are for welding. The accessory pack contains sealing washers' etc, for use with the service valves.

**NOTE**
It will be necessary to hold the valve with one spanner whilst tightening with another

### 4.6.1 GAS (fig. 16)

The appliance is supplied with a 22mm service valve, connect a 22mm pipe to the inlet of the valve and tighten both nuts.

**NOTE**
It will be necessary to calculate the diameter of the gas supply pipe to ensure the appliance has an adequate supply of gas.

### 4.6.2 FLOW & RETURN (fig. 16)

The appliance is supplied with 22mm service valves for the flow and return connections, connect a 22mm pipe to the inlet of each valve and tighten both nuts.

**NOTE**
Depending on system requirements, it may necessary to increase the size of the flow & return pipe work after the service valve connections.


Fig. 15



Fig. 16

**4.6.3 SAFETY VALVE (fig. 16)**
Connect the safety valve connection pipe to the safety valve outlet. Connect a discharge pipe to the other end of the safety valve connection pipe and tighten. The discharge pipe must have a continuous fall away from the appliance to outside and allow any water to drain away thereby eliminating the possibility of freezing. The discharge pipe must terminate in a position where any water – possibly boiling – discharges safely without causing damage or injury, but is still visible.

**4.6.4 CONDENSE PIPE**
During normal operation the boiler produces condense which is collected in a trap located in the lower part of the boiler. A flexible pipe (condense outlet pipe) is connected to the outlet of the trap. The flexible pipe must be connected to a plastic waste pipe only. The plastic waste pipe must have a minimum of a 3º fall towards the drain. Any external run of pipe should be insulated to prevent the risk of freezing.

**4.6.5 CONNECTING THE CONDENSATE OUTLET**
Gently pull the condense outlet pipe down from its location inside the boiler until approximately 100mm protrudes from the underside of the boiler. Connect a suitable plastic (not copper) pipe (no less than 20mm diameter) to the outlet pipe and ensure it discharges in accordance with building regulations or other rules in force.

## 4.7 ELECTRICAL CONNECTIONS

The boiler is supplied with a 2-metre fly-lead. This lead can be used for connection to the electrical supply. Connect the fly-lead to a fused plug or fused isolator in the following way:
- brown wire to LIVE supply
- blue wire to NEUTRAL supply
- green/yellow to EARTH connection.

Insert the supplied 3-AMP fuse into the fused isolator or fused plug.

Should the fly-lead be unsuitable, refer to 4.7.3 for details on how to connect the electrical supply directly to the boiler.

The electrical supply must be as specified in section 3/3A. A qualified electrician should connect the appliance to the electrical supply. If controls - external to the appliance - are required, a competent person must undertake the design of any external electrical circuits, please refer to section 8 for detailed instructions. ANY EXTERNAL CONTROL OR WIRING MUST BE SERVED FROM THE SAME ISOLATOR AS THAT OF THE APPLIANCE. The supply cable from the isolator to the appliance must be 3-core flexible sized 0.75mm to BS 6500 or equivalent. Wiring to the appliance must be rated for operation in contact with surfaces up to 90 ºC.

**4.7.1 CASING REMOVAL (fig. 17)**
To gain internal access to the appliance you must first remove the casing, proceed as outlined below:
- locate and unscrew the 2-screws (**A**) that secure the outer casing to the appliance
- lift the casing upward to disengage it from the top locating hooks and then remove
- store the casing and screws safely until required. Re-fit in the reverse order
- gently lower the control fascia until it rests.

**4.7.2 APPLIANCE TERMINAL BLOCK**
The appliance terminal block is located on the rear of the control fascia. Remove the casing as described in 4.7.1. Gently pull the control panel forwards and down. Locate the terminal block cover (fig. 18).

**NOTE**
The appliance comes with a factory fitted link ('TA') to allow basic operation of the boiler via the mode selector switch. If it is anticipated that external controls will be required please refer to the wiring diagrams in section 8 for more detailed information.

**4.7.3 CONNECTING THE MAINS (230V) INPUT**
Unhook and remove the terminal block cover (230V). Pass the cable through the cable anchorage point. Connect the supply cable wires (LIVE, NEUTRAL, & EARTH) to their corresponding terminals (L, N, & E) on the appliance – high voltage – terminal block. When connecting the EARTH wire, ensure that it's left slightly longer that the others, this will prevent strain on the EARTH wire should the cable become taut. Do not remove the link wire unless additional external controls are to be fitted (see section 8). The securing screw on the cable anchorage should now be tightened. This must be done before the terminal block cover is re-fitted in its position.

**NOTE**
It is the installer's responsibility to ensure that the appliance is properly Earthed. Vokèra Ltd. cannot be held responsible for any damages or injuries caused as a result of incorrect Earth wiring.



Fig. 17


Fig. 18

# SECTION 5 - COMMISSIONING

## 5.1 GAS SUPPLY INSTALLATION

Inspect the entire installation including the gas meter, test for tightness and purge. Refer to BS 6891 (I.S. 813 in ROI) for specific instruction.

## 5.2 THE HEATING SYSTEM

The appliance contains components that may become damaged or rendered inoperable by oils and/or debris that are residual from the installation of the system, consequently it is essential that the system be flushed in accordance with the following instructions.

## 5.3 INITIAL FILLING OF THE SYSTEM

Ensure both flow and return service valves are open, remove appliance casing as described in 4.7.1, identify the automatic air release valves (AAV) and loosen the dust cap/s by turning the cap anti-clockwise one full turn. Ensure all manual air release valves located on the heating system are closed. Connect the filling loop as shown in fig. 5, slowly proceed to fill the system by firstly opening the inlet valve connected to the flow pipe, and then turning the lever on the fill valve, to the open position. As water enters the system the pressure gauge will begin to rise. Once the gauge has reached 1 BAR close both valves and begin venting all manual air release valves, starting at the lowest first. It may be necessary to go back and top-up the pressure until the entire system has been filled. Inspect the system for water tightness, rectifying any leaks.

### 5.3.1 MANUAL AIR RELEASE (fig. 19)

When the boiler has been filled for the first time or the system has been drained and refilled, it will be necessary to release any air that may have become trapped within the appliance heat exchanger. Slacken the bleed screw until water is released and then close.

**IMPORTANT, THERE ARE NO OTHER MANUAL AIR RELEASE VALVES LOCATED ON THE APPLIANCE.**



Fig. 19

## 5.4 INITIAL FLUSHING OF THE SYSTEM

The whole of the heating system must be flushed both cold and hot as detailed in 5.8. Open all radiator or heating valves and the appliance flow & return service valve. Drain the boiler and system from the lowest points. Open the drain valve full bore to remove any installation debris from the boiler prior to lighting. Refill the boiler and heating system as described in 5.3.

## 5.5 PRE-OPERATION CHECKS

Before attempting the initial lighting of the appliance, the following checks must be carried out:

- ensure all gas service valves from the meter to the appliance are open and the supply pipe has been properly purged;
- ensure the proper electrical checks have been carried out, (see 7.8) particularly continuity, polarity and resistance to earth;
- ensure the 3 AMP fuse – supplied with the appliance – has been fitted;
- ensure the system has been filled, vented and the pressure set to 1 BAR;
- ensure the flue system has been fitted properly and in accordance with the instructions;
- ensure all appliance service valves are open.

## 5.6 INITIAL LIGHTING

Ensure the electrical supply to the appliance is switched on. Ensure any external controls are switched to an 'ON' position and are calling for heat. Move the selector switch to the ON position, the appliance will now operate as described in 1.2. Should the appliance fail to ignite, refer to 5.6 and/or section 7 (mode of operation, parameter setting & faultfinding).

## 5.7 CHECKING GAS PRESSURE AND COMBUSTION ANALYSIS

The appliance is factory set and requires no additional adjustment once installed. However to satisfy the requirements of GSIUR 26/9 (I.S. 813 ROI), it will be necessary to gas rate the appliance using the gas meter that serves the appliance.
If the installation does not include a gas meter (for example LPG) and there are no means by which to calculate the gas rate, then a combustion analysis test must be carried out in accordance with BS 7967 (UK) to ensure the appliance is left working safely and correctly.
Additionally, if the gas valve has been adjusted, replaced, or the appliance has been converted for use with another gas type, then it becomes necessary to carry out a combustion analysis/check to ensure that correct combustion is occurring. If there are no means to gas rate the appliance and/or carry out a combustion analysis check, then it will not be possible to complete the commissioning procedure.
Details on how to carry out the combustion analysis can be found in section 7.

**IMPORTANT**

It's imperative that a sufficient dynamic – gas – pressure is maintained at all times. Should the dynamic gas pressure fall below an acceptable level, the appliance may malfunction or sustain damage.

## 5.8 FINAL FLUSHING OF THE HEATING SYSTEM

The system shall be flushed in accordance with BS 7593 (I.S. 813 ROI). Should a cleanser be used, it must be suitable for Aluminium heat exchangers. It shall be from a reputable manufacturer and shall be administered in strict accordance with the manufacturers' instructions and the DWTA code of practice.

**NOTE**

Chemicals used to cleanse the system and/or inhibit corrosion must be pH neutral, i.e. they should ensure that the level of the pH in the system water remains neutral. Premature failure of certain components can occur if the level of pH in the system water is out-with normal levels.

### 5.8.1 INHIBITORS

See Section 3 "General Requirements".

## 5.9 SETTING THE FLOW OUTLET TEMPERATURE

The flow outlet temperature can be adjusted between 40 °C - 80 °C for standard CH system by using the Heating thermostat knob (see fig.1).

## 5.10 SETTING THE SYSTEM DESIGN PRESSURE

The design pressure should be a minimum of 0.5 BAR and a maximum of 1.5 BAR. The actual reading should ideally be 1 BAR plus the equivalent height in metres (0.1 BAR = 1 metre) to the highest point in the system above the base of the appliance (up to the maximum of 1.5 BAR total).

**N.B.** The safety valve is set to lift at 3 BAR/30 metres/45 psig. To lower the system pressure to the required value, drain off some water from the appliance drain valve until the required figure registers on the pressure gauge (see fig. 1).

## 5.11 REGULATING THE CENTRAL HEATING SYSTEM

Fully open all radiator and circuit valves and run the appliance for both heating and hot water until heated water is circulating. If conditions are warm remove any thermostatic heads. Adjust radiator return valves and any branch circuit return valves until the individual return temperatures are correct and are approximately equal.

## 5.12 FINAL CHECKS

- ENSURE ALL TEST NIPPLES ON THE APPLIANCE GAS VALVE ARE TIGHT AND CHECKED FOR TIGHTNESS.
- ENSURE THE APPLIANCE FLUE SYSTEM IS FITTED CORRECTLY AND IS PROPERLY SECURED.
- ENSURE ALL PIPE WORK IS RE-CHECKED FOR TIGHTNESS.
- RE-FIT APPLIANCE CASING.
- COMPLETE BENCHMARK CHECKLIST.

**FOR UK ONLY**

Complete details of the boiler, controls, installation and commissioning in the Benchmark checklist at the back of this book. It is important that the Benchmark checklist is correctly completed and handed to the user. Failure to install and commission the appliance to the manufacturers instructions may invalidate the warranty.

## 5.13 INSTRUCTING THE USER

Hand over all documentation supplied with this appliance – including these instructions – and explain the importance of keeping them in a safe place.

Explain to the user how to isolate the appliance from the gas, water and electricity supplies and the locations of all drain points. Show the user how to operate the appliance and any associated controls correctly.

Show the user the location of the filling valve and how to top-up the system pressure correctly and show the location of all manual air release points.

Explain to the user how to turn off the appliance for both long and short periods and advise on the necessary precautions to prevent frost damage.

Explain to the user that for continued safe and efficient operation, the appliance must be serviced annually by a competent person.

**IMPORTANT**

To validate the appliance warranty, it's necessary to register the appliance details with us. The warranty can be registered in several ways:

- by completing the warranty registration card and posting to us using the envelope supplied
- online at: vokera.co.uk
- for UK residents by calling: 0870 607 0281
- for ROI residents by calling: 056 6655057.

# SECTION 6 - SERVICING INSTRUCTIONS

## 6.1 GENERAL

To ensure the continued safe and efficient operation of the appliance, it is recommended that it is checked and serviced at regular intervals. To ensure correct and safe operation of the appliance, it is essential that any worn or failed component be replaced only with a **genuine Vokèra spare part**. It should be remembered that although certain generic components may look similar, they will be specific to an individual appliance or product range. Use of non-genuine Vokèra spare parts could invalidate your warranty and may pose a potential safety hazard. The frequency of servicing will depend upon the particular installation conditions, but in general, once per year should be sufficient. It is the law that any servicing work is carried out by competent person such as a Vokèra engineer, an approved service agent, British Gas, GAS SAFE registered personnel or other suitably qualified personnel. The following instructions apply to the appliance and its controls, but it should be remembered that the central heating and the domestic hot water systems would also require attention from time to time.

## 6.2 ROUTINE ANNUAL SERVICING

- Check the operation of the appliance and ensure it functions as described in section 7.
- Compare the performance of the appliance with its design specification. The cause of any noticeable deterioration should be identified and rectified without delay.
- Thoroughly inspect the appliance for signs of damage or deterioration especially the flue system and the electrical apparatus.
- Check and adjust – if necessary – all burner pressure settings (see 7.4).
- Check and adjust – if necessary – the system design pressure (see 5.10).
- Carry out an analysis of the flue gases (see 7.5), and visually check the condition of the entire flue assembly.
- Compare the results with the appliance design specification. Any deterioration in performance must be identified and rectified without delay.
- Check that the burner and main heat exchanger are clean and free from any debris or obstruction.
- Check and clean – if necessary – the condense trap to ensure correct operation.

## 6.3 REPLACEMENT OF COMPONENTS

Although it is anticipated that this appliance will give years of reliable, trouble free service, the life span of components will be determined by factors such as operating conditions and usage. Should the appliance develop a fault, the fault finding section will assist in determining which component is malfunctioning.

## 6.4 COMPONENT REMOVAL PROCEDURE

To remove a component, access to the interior of the appliance is essential. Isolate the appliance from the electrical supply and remove the fuse. And when necessary, close all service valves on the appliance, remove the appliance casing as described in section 4.7.1 and drain the water content from the appliance via the drain valve. Ensure some water absorbent cloths are available to catch any residual water that may drip from the appliance or removed component. Undertake a complete commissioning check as detailed in section 5, after replacing any component. **ALWAYS TEST FOR GAS TIGHTNESS IF ANY GAS CARRYING COMPONENTS HAVE BEEN REMOVED OR DISTURBED.**

**6.4.1 AIR BOX FRONT COVER REMOVAL (fig. 20)**

Locate the 4 screws and remove air box front cover.

## 6.5 PUMP ASSEMBLY (fig. 21)

Carry out component removal procedure as described in 6.4. Disconnect and remove the pump outlet pipe (**A**) from the pump assembly/combustion chamber connection.
Remove the expansion pipe locking pin (**B**) from the top of the pump assembly and withdraw the flexible pipe. Locate and remove the pressure gauge securing pin (**C**) and disconnect the pressure gauge from the pump assembly. Disconnect the electrical wiring from the pump's electrical connection point (**D**). Locate and remove the 2 securing screws (**E**) at the rear of the pump assembly. Remove locking pin (**F**) from pump base and lift pump assembly clear of the hydraulic manifold. The pump assembly can now be removed from the appliance. Replace carefully in the reverse order.


Fig. 20

## 6.6 SAFETY VALVE (fig. 22)

Carry out component removal procedure as described in 6.4. Disconnect the outlet pipe (**G**) from the safety valve, remove safety valve locking pin (**H**) from the hydraulic manifold. Replace in the reverse order.

## 6.7 LOWER AUTOMATIC AIR RELEASE VALVE (fig. 21)

Carry out component removal procedure as described in 6.4. Remove the expansion pipe locking pin (**B**) from the pump assembly and remove the expansion pipe. Locate and remove the AAV locking pin (**I**) from the pump assembly and remove the AAV assembly (**J**). Replace in the reverse order.

### 6.7.1 TOP AUTOMATIC AIR RELEASE VALVE (fig. 23)

Carry out component removal procedure as described in 6.4. Remove the AAV locking pin (**K**) from the deaerator assembly and remove the AAV assembly (**L**). Replace in the reverse order.



Fig. 21

## 6.8 WATER PRESSURE SWITCH (fig. 24)

Carry out component removal procedure as described in 6.4. Locate and remove the locking pin (**M**) from the water pressure switch (**N**). Remove the wiring. Carefully withdraw the switch. Replace in the reverse order.



Fig. 22



Fig. 23

## 6.9 FLOW THERMISTOR (fig. 4 - pos. 15)

Carry out component removal procedure as described in 6.4. Unclip and remove the air chamber front cover. Unclip the flow thermistor from the flow outlet pipe. Disconnect thermistor electrical plug. Replace in the reverse order.

## 6.10 RETURN THERMISTOR (fig. 4 - pos. 18)

Carry out component removal procedure as described in 6.4. Unclip and remove the air chamber front cover. Unclip the return thermistor from the return inlet pipe. Disconnect thermistor electrical plug. Replace in the reverse order.

## 6.11 PRINTED CIRCUIT BOARD (fig. 25)

Carry out component removal procedure as described in 6.4. Pull the control fascia forward and lower it. Push the clips (**O**) which secure the PCB cover, remove cover, after carefully taking note of all wiring connections and jumper tag configuration. Unhook and remove connection block (**P**). Disconnect all wiring from the PCB, locate and remove the PCB securing screws, remove the required PCB. Replace in the reverse order ensuring that the position of the 2 control knobs are correctly aligned with the respective potentiometers on the PCB.
Ensure that the correct jumper tag configuration has been respected. It will be necessary to check the functioning of the PCB is set for the correct boiler type/application.



Fig. 24



Fig. 25

## 6.12 GAS VALVE (fig. 26)

Carry out component removal procedure as described in 6.4. The gas valve must be changed as complete unit. Disconnect the electrical plug and leads from the gas valve, slacken and unscrew gas valve inlet and outlet connections. **Please note,** the sealing washers (**Q**) must be discarded and replaced with new sealing washers. Disconnect the compensation pipe (**R**). Unscrew gas pipe connections (**S-T**), the gas valve can now be removed. Replace in the reverse order. Check and adjust burner pressure settings.
**WARNING, A GAS TIGHTNESS CHECK MUST BE CARRIED OUT.**



Fig. 26

#### 6.12.1 INJECTOR (fig. 26)

Carry out component removal procedure as described in 6.4. Unscrew and remove gas pipe connections (**S-T**). Locate and remove the injector (**U**) inside the pipe. Replace in the reverse order. Check and adjust burner pressure settings.
**WARNING, A GAS TIGHTNESS CHECK MUST BE CARRIED OUT.**

## 6.13 ELECTRODES (fig. 27)

Carry out component removal procedure as described in 6.4. Remove the air chamber front cover. Disconnect the electrode leads and ancillary wiring from their respective connectors. Remove the retaining screws (**V**) for electrode. Remove the spark ignition electrode (**W**). Remove the flame sensor electrod (**Y**).



Fig. 27

## 6.14 FLUE FAN & MIXER (fig. 28-29)

Carry out component removal procedure as described in 6.4. Remove the air chamber front cover. Locate and remove the gas pipe locking pin (**A1**) and swing/rotate the gas pipe away from the fan assembly (**B1**), (if necessary unscrew the gas pipe from the gas valve **G1**). Locate and slacken the silencer (**H1**). Locate and remove the sense electrode. To remove the fan (**E1**), disconnect the electrical connections attached to the fan, locate and remove the four screws (**F1**). Gently ease the fan from its location. To remove the mixer (**C1**) locate and remove the three screws (**D1**), the mixer can be removed after the fan removal. Replace in the reverse order. Ensure all seals are in good condition, taking care to ensure they are replaced correctly.

## 6.15 BURNER (fig. 28)

Carry out component removal procedure as described in 6.4. Remove the air chamber front cover. Locate and remove the gas pipe locking pin (**A1**) and swing/rotate the gas pipe away from the fan assembly (**B1**), (if necessary unscrew the gas pipe from the gas valve **G1**). Locate and slacken the silencer (**H1**), disconnect the electrical connections attached to the fan. Disconnect the electrode leads and ancillary wiring from their respective connectors. Locate and remove the screws (**I1**) which secure the burner assembly in position to the heat exchanger (**J1**). Gently ease the fan assembly out of its location. Once the assembly has been removed, the burner (**K1**) can be withdrawn from the heat engine. Ensure the seals (**L1**) is in good condition, taking care to ensure it is replaced correctly. Replace in the reverse order.



Fig. 28

## 6.16 MAIN HEAT EXCHANGER (fig. 29)

Carry out component removal procedure as described in 6.4. Remove the air chamber front cover. Locate and remove the gas pipe locking pin (**A1**) and swing/rotate the gas pipe away from the fan assembly (**B1**), (if necessary unscrew the gas pipe from the gas valve **G1**). Disconnect the electrical connections attached to the fan. Disconnect the electrode leads and ancillary wiring from their respective connectors.
Disconnect the flow locking pin (**M1**), return locking pin (**N1**) on the heat exchanger. Locate and remove the 5-screws that secure the heat exchanger to the combustion chamber (**O1**). Move the heat exchanger and disconnect it from the flue collector (**P1**). The heat exchanger can now be lifted up and withdrawn from the appliance.
Replace in the reverse order. Ensure all seals are in good condition, taking care to ensure they are replaced correctly.



Fig. 29

## 6.17 AUTOMATIC BY-PAS (fig. 30)

Carry out component removal procedure as described in 6.4. Remove the locking pin (**Q1**) that secures the cover (**R1**) to the hydraulic manifold. Using a hooked piece of wire, carefully withdraw the by-pass cartridge (**S1**). Ensure all seals are in good condition, taking care to ensure they are replaced correctly. Replace in the reverse order ensuring the cartridge is facing the correct way.



Fig. 30

## 6.18 EXPANSION VESSEL REMOVAL (fig. 31)

Carry out component removal procedure as described in 6.4. Disconnect the expansion vessel from the flexible expansion pipe. Disconnect the flexible expansion pipe from the vessel. Unscrew the nut that secures the vessel to the lower frame. Locate and remove the screw (**U1**) that secure the vessel to the top. The expansion vessel can now be removed. Replace in the reverse order. Ensure all seals are in good condition, taking care to ensure they are replaced correctly.



Fig. 31

## 6.19 CONDENSE TRAP REMOVAL (fig. 32)

Carry out component removal procedure as described in 6.4. Disconnect the the locking pin (**V1**) that secures the trap to the air condense pipe. Disconnect the lower rubber condense pipe from the condense trap. Carefully remove the condense trap. For cleaning unlock the upper and lower closing plug (**W1**). Replace in the reverse order.



Fig. 32

## 6.20 FLUE COLLECTOR REMOVAL (fig. 33)

Carry out component removal procedure as described in 6.4. Remove the air chamber front cover. Remove the heat exchanger as per 6.16. Locate and remove the screw (**Y1**) that secures the flue gas analysis test point cover (**Z1**). Disconnect the flues thermistor wiring connections. Locate and remove the 4 screws (**A2**). Locate and remove the 2 screws (**A3**). Gently ease the condensate collector (**A4**) out off its location. Gently ease the flue collector out off its location. Replace in the reverse order.



Fig. 33

# SECTION 7 - CHECKS, ADJUSTMENTS AND FAULT FINDING

## 7.1 CHECKING APPLIANCE OPERATION

When carrying out any repairs or servicing to the appliance, the relevant commissioning procedure must be undertaken to ensure the continued safe operation of the appliance. Particular attention should be made to ensure gas tightness, water tightness and the electrical integrity of the appliance.

## 7.2 APPLIANCE MODES OF OPERATION

**NOTE**
There must be sufficient system water pressure (min. 0.5 bar) to ensure the water pressure switch is activated. If there is insufficient system pressure the pump and fan will be prevented from operating and the low-pressure fault code will be indicated.

### 7.2.1 SELECTOR SWITCH IN THE OFF/RESET POSITION

When the selector switch is in the OFF/RESET position, the following functions are active.

**Active functions**:
- frost-protection system
- pump anti-block.

### 7.2.2 ON-BOARD FUNCTIONS

- **CO FUNCTION:** the CO function when activated, will allow the appliance to run at CH maximum, whilst a combustion analysis check or a mechanical gas valve calibration is being carried out. Whilst the CO function is active, all other functions are disabled (minimum power operating period, anti-cycle, set-point, etc). Once enabled, the CO function will remain active for a 15-minute period, or until the function is manually deactivated.
- **FROST-PROTECTION:** this function is only active when there are no requests for heating or HW. If the temperature drops below 5°C, the boiler will operate on minimum power until the temperature of the thermistors reaches 35°C . Thereafter the pump & fan will over-run for 30-seconds.
- **ANTI-CYCLE FUNCTION:** the anti-cycle function ensures the burner remains switched off for at least 3-minutes after the set-point hysterisis (set-point + 5-deg) for CH heat request.
- **PUMP ANTI-BLOCK FUNCTION:** when there has been no heating or HW request for 24-hours, the anti-block cycle is activated. The pump will be activated for a period of 30-seconds.
- **SARA function:** the SARA function permits the boiler (when the set-point is within the SARA range) to automatically adjust (raise) the heating flow outlet temperature should the room thermostat contacts remain closed for more that 20-minutes.

### 7.2.3 HEATING MODE

With the selector switch in the heating & hot water position and any additional controls (time clock, programmer, room thermostat, etc.) calling for heat, the appliance will operate in the heating mode. The pump and fan will be activated via the flow temperature sensor. When the fan is sensed to be operating correctly (tacho signal), the ignition sequence commences. Ignition is sensed by the electronic circuit to ensure flame stability at the burner. Once successful ignition has been achieved, the electronic circuitry increases the gas rate to 75% for a period of 15 minutes.
The speed of the fan and therefore the output of the boiler is determined by the temperature of the water sensed by the flow temperature sensor, consequently a high temperature at the flow sensor results in a lower fan speed. As the water temperature increases, the temperature sensors – located on the flow pipe of the boiler – reduce the fan speed via the electronic circuitry. Depending on the load, either the water temperature will continue to rise until the set point is achieved or the water temperature will fall whereby fan speed will increase relative to the output required. When the boiler has reached the set point (+ hysterisis), the burner will switch off. The built-in anti-cycle device prevents the burner from re-lighting for approximately 3-minutes. When the temperature of the flow sensor falls below the set point (- hysterisis), the burner will re-light.

**NOTE**
If the spark/sensing electrode does not sense ignition the appliance will re-attempt ignition a further 4-times then go to lockout. When the set-point has been reached (the position of the heating temperature selector) as measured at the primary thermistor, the appliance will begin the modulation phase whereby the fan and gas valve will continuously modulate to maintain the set-point.
If the temperature continues to rise and exceeds the set-point by 5°C (hysterisis), the burner will shut down. A new ignition sequence will be enabled when the 3- minute anti-cycle has been performed and the temperature at the primary thermistor has dropped 5°C (hysterisis) below the set-point.

**ATTENTION**
Gas type and appliance output **must be set** according to the specific appliance specification. Vokèra accepts no responsibility if the gas type is not correctly adjusted according to the respective appliance specification as detailed on the appliance data badge.

## 7.3 CHECKING THE $CO_2$ AND ADJUSTING THE GAS VALVE

THE GAS VALVE MUST BE SET-UP OR ADJUSTED WITH THE AID OF A PROPERLY CALIBRATED FLUE GAS ANALYSER.
Isolate the appliance from the electrical supply and remove the appliance casing as described in 4.7.1. Set the flue gas analyser to read $CO_2$ and insert the probe into the flue analysis test point (**Y1-Z1** fig. 33). Restore the electrical supply to the boiler and switch the boiler to the OFF mode.
Have access to the printed circuit board, locate and open the closing plug on the dash board (**L2**), locate and press the CO button (see fig. 36 pos. **SW1**). Press the button the number of timing according the function requirement as par 7.3.1.




Fig. 36

### 7.3.1 $CO_2$ FUNCTION SETTINGS

Locate the CO button (see 7.3)

Select the main selector switch in position ⏻

| $CO_2$ FUNCTIONS | ACTION ON THE BUTTON | LED STATUS |
|---|---|---|
| combustion analysis mode | press once = burner running at maximum heating | yellow led blinking |
| gas valve maximun setting (*) | press twice = burner running at maximum absolute | yellow led blinking + red led fixed |
| gas valve minimum setting | press three time = burner running at minimum | yellow led blinking + green led fixed |

(*) this step has not to be used for the system boiler. If you find in this situation press the button once again.

**NOTE**

1 - Any additional pressing of CO button after the third time the burner switched between maximum absolute and minimum.

2 - To restart the CO function it is necessary to pass throught the ⏻ position with the main selector switch

### 7.3.2 GAS VALVE MAXIMUM SETTING

Set the $CO_2$ button at maximum heating (see 7.3.1), once the maximum heating is obtained (only yellow led blinking) check that it corresponds with the appropriate $CO_2$ value (Maximum) for the respective appliance (see 2.11). If the $CO_2$ reading is correct, proceed to gas valve minimum setting (7.3.3).
However, if the $CO_2$ reading is incorrect, the maximum gas pressure must be adjusted as follows:

- using a TX 15 key (Torx key), very slowly turn the maximum adjustment screw (see fig. 37) - clockwise to increase, counter clockwise to decrease - until the correct value is displayed on the $CO_2$ analyser (allow time for the analyser to stabilise).

### 7.3.3 GAS VALVE MINIMUM SETTING

Set the $CO_2$ button at minimum (see 7.3.1), once the minimum is obtained (yellow led blinking + green led fixed) check that it corresponds with the appropriate $CO_2$ value (Minimum) for the respective appliance (see 2.11). If the $CO_2$ reading is correct, proceed to completion (7.3.4).
However, if the $CO_2$ reading is incorrect, the minimum gas pressure must be adjusted as follows:

- locate the minimum adjustment screw (fig. 37), remove the protection plug using a TX 15 key (Torx key)
- using a TX 15 key (Torx key), very slowly turn the minimum adjustment screw (see fig. 37) - clockwise to increase, counter clockwise to decrease - until the correct value is displayed on the $CO_2$ analyser (allow time for the analyser to stabilise).

### 7.3.4 COMPLETION

On completion of the combustion analysis check and/or any gas valve adjustment, refit the plug (fig. 36 **L2)** and move the mode selector throught ⏻ position. Remove the test probe from the test point and refit the sealing screw/s and/or cap.

**IMPORTANT**
**A GAS TIGHTNESS CHECK MUST BE CARRIED OUT IF ANY GAS CARRYING COMPONENTS HAVE BEEN REMOVED, REPLACED OR DISTURBED.**

## 7.4 COMBUSTION ANALYSIS TEST

A combustion analysis check can easily be carried out on the appliance via the test points located on the top of the appliance (see 7.3).

- Insert the flue gas analyser probe into the flue gas test point (see fig. 33).
- Operate the boiler in combustion analysis mode (see 7.3.1) and compare the values with those shown in section 2 (Nat. Gas) or section 10 (LPG). If different adjust the gas valve according to 7.3.1, 7.3.2, & 7.3.3.

**Note** An existing boiler with a measured $CO/CO_2$ ratio of 0.004/1 or less can be deemed as operating satisfactorily, with a measured $CO/CO_2$ ratio of greater than 0.004/1 can be deemed as at risk, with a measured $CO/CO_2$ ratio of greater than 0.008/1 can be deemed as immediately dangerous.

## 7.5 CHECKING THE EXPANSION VESSEL

Carry out the component removal procedure as described in 6.4. You must ensure that the boiler is completely drained of water. Using a suitable pressure gauge, remove dust cap on expansion vessel and check the charge pressure. The correct charge pressure should be 1.0 bar ± 0.1 bar. If the charge pressure is less, use a suitable pump to increase the charge.



fig. 37

**NOTE**
You must ensure the drain valve is in the open position whilst re-charging takes place. Replace the dust cap and carry out the relevant commissioning procedure (section 5).

## 7.6 EXTERNAL FAULTS

Before carrying out any faultfinding or component replacement, ensure the fault is not attributable to any aspect of the installation.

### 7.6.1 INSTALLATION FAULTS

| Symptom | Possible cause |
|---|---|
| No led/ignition | Check wiring/check electrical supply |
| No hot water | Check pipe-work |
| No heating | Check external controls |

| Fault | Possible cause |
|---|---|
| Red led fixed | Check gas supply, check flue system, check polarity |

## 7.7 ELECTRICAL CHECKS

Any electrical checks must be carried out by a suitably qualified person.

### 7.7.1 EARTH CONTINUITY TEST

Isolate the appliance from the electrical supply, and using a suitable multi-meter carry out a resistance test. Connect test leads between an appliance earth point and the earth wire of the appliance supply cable. The resistance should be less than 1 OHM. If the resistance is greater than 1 OHM check all earth wires and connectors for continuity and integrity.

### 7.7.2 SHORT CIRCUIT CHECK

Isolate the appliance from the electrical supply, and using a suitable multi-meter, carry out a short circuit test between the Live & Neutral connections at the appliance terminal strip. Repeat above test on the Live & Earth connections at the appliance terminal strip.

**NOTE**
Should it be found that the fuse has failed but no fault is indicated, a detailed continuity check will be required to trace the fault. A visual inspection of components may also assist in locating the fault.

**7.7.3 POLARITY CHECK**
With the appliance connected to the electrical supply and using a suitable multimeter, carry out the following voltage tests:

- connect test leads between the Live & Neutral connections at the appliance terminal strip. The meter should read approximately 230V ac. If so proceed to next stage. If not, see 7.7.4.
- connect test leads between the Live & Earth connections at the appliance terminal strip. The meter should read approximately 230V ac. If so proceed to next stage. If not, see 7.7.4.
- connect test leads between the Neutral & Earth connections at the appliance terminal strip. The meter should read approximately 0 – 15Vac. If so polarity is correct. If not, see 7.7.4.

**7.7.4 REVERSED POLARITY OR SUPPLY FAULT**
Repeat the above tests at the appliance isolator, if testing reveals correct polarity and/or supply at the isolator, re-check wiring and connections between the isolator and the appliance. If tests on the isolator also reveal reversed polarity or a supply fault, consult the local electricity supplier for advice.

**7.7.5 RESISTANCE TO EARTH CHECK**
Isolate the appliance from the electrical supply, and using a suitable multi-meter carry out a resistance test. Connect test leads between the Live & Earth connections at the appliance terminal strip. If the meter reads other than infinity there is a fault that must be isolated, carry out a detailed continuity check to identify the location of the fault.
These series of checks must be carried out before attempting any faultfinding procedures on the appliance. On completion of any task that required the disconnection and re-connection of any electrical wiring or component, these checks must be repeated.

## 7.8 FAULT FINDING

Before attempting any faultfinding, the electrical checks as detailed in 7.7 must be carried out. Isolate the appliance from the electrical supply.
Disconnect any external controls from terminal plug (CN5 fig. 39), and insert a link-wire between the two wires at the 'TA' connections.
**NOTE**
Restore the electrical supply to the boiler and turn the selector switch to the on position. The boiler should now function as described in section 7. Should the boiler fail to respond, the internal fuses and connectors should be checked to ensure integrity and continuity.

## 7.9 COMPONENT VALUES & CHARACTERISTICS

| **COMPONENT** | **VALUE** |
|---|---|
| Fan | 230Vac |
| Pump | 230Vac |
| Ignition transformer | 230Vac |
| Gas valve | 230Vac |
| Room thermostat connection | 24Vdc |
| NTC thermistor (dry contact) | 10Kohm |
| NTC thermistor (wet contact) | 10Kohm |
| **FUNCTION** | **VALUE** |
| Standard Heating temperature range (min – max °C) | 40 - 80 |
| 75% maximum CH time | 15 min |
| Heating OFF hysterisis (°C) | SP + 5 |
| Heating ON hysterisis (°C) | SP – 5 |
| Anti-cycle delay | 3-min |
| Pump over-run | 30-sec |
| Low output (min. output + %) | Min+25 |
| CO function max temp. (°C) | 90 |
| CO re-light temp. (°C) | 78 |
| CO function time | 15-min |
| Flow NTC max temp. (°C) | 90 |
| High limit thermostat (°C) | 105 |
| Flue NTC max temp. (°C) | 125 |
| Maximum differential (°C) | 35 |
| **IGNITION CONTROL** | **VALUE** |
| Ignition attempts before L/O (lockout) | 5 |
| Re-ignition attempts after loss of flame signal | 5 |

## APPLIANCE STATUS LED AND FAULT CODES

When the boiler detects a temporary fault condition, the appropriate led indication is shown. If/when the fault is final, the pump will perform a 60-second post circulation and rel LED will be illuminated. See table on pag. 4.

# SECTION 8 - WIRING DIAGRAMS

## 8.1 EXTERNAL WIRING

The appliance comes with a factory fitted (TA) link to allow basic operation of the boiler via the mode selector switch. If external controls are to be added to the system, they must be connected to the appliance as shown in the following diagrams. For advice on controls that are not featured in this book, please contact Vokera technical on **0844 3910999**

### 8.1.1 EXTERNAL WIRING LIMITATIONS

Any external wiring must remain within the limits as detailed in the table below

| CONNECTION | MAX. LENGTH |
|---|---|
| Room thermostat | 30-metres |




Fig. 38a

## 8.2 TYPICAL CONTROL APPLICATIONS

The appliance can be used with the following controls:

- single-channel, voltage-free time clocks (fig. 38a)
- programmable room thermostats (fig. 38b)
- twin-channel programmers.

The appliance can be used in conjunction with typical 'S'-Plan systems, for 'Y'-Plan systems, a relay is required, please contact Vokera technical should you require further detailed instruction.




Fig. 38b

## 8.3 OTHER DEVICES

Contact the controls manufacturer and/or Vokera technical department should you require more specific information on the suitability of a particular control. Further guidance on the recommended practice for the installation of external controls, can be found in CHeSS – HC5/HC6 (www.energyefficiency.gov.uk).




Fig. 39

# FUNCTIONAL DIAGRAM

Fig. 40

**NOTE: L-N-E connection is advisable**




CN1-CN15 Connectors - **(CN4 Unused – CN5 room thermostat (24 Vdc)**

| | |
|---|---|
| S.W. | CO2 function button |
| F.S. (1) | Flame sensor |
| F1 | Fuse 3.15A T |
| F | External fuse 3.15A F |
| M3 | Terminal strip for electrical connection hight power |
| P | Pump |
| OPE | Gas valve solenoids |
| F Hv | Fan power supply 230 V |
| F Lv | Fan signal control |
| WPS | Water pressure switch |
| S.E. | Spark electrode |
| TSC2 | Ignition transformer |
| F.O.H.T | Flow over heat thermostat |
| FS | Flue sensor |
| FT | Flow thermistor (NTC) |
| RS | Return thermistor (NTC) |

| | |
|---|---|
| AKL | Main PCB |
| P1 | Selector switch and heating potentiometer |
| P2 | **Unused** |
| P3 | **Unused** |
| P4 | **Unused** |
| JP1 | **Unused** |
| JP2 | **Unused** |
| JP3 | **Unused** |
| JP4 | **Unused** |
| JP5 | Selection operating only heating |
| JP6 | **Unused** |
| JP7 | **Unused** |
| JP8 | Closed - **Unused** |
| LED | Led 1 (green) working status or temporary stop |
| | Led 2 (yellow) CO2 function ON |
| | Led 3 (red) boiler lock out |

# SECTION 9 - EXPLODED DIAGRAMS

**Table 1**




| POS. | DESCRIPTION | 25 |
|---|---|---|
| 2 | Frame assembly | 20011411 |
| 12 | Quick primer pressure gauge | 20005580 |
| 18 | Control panel cover | 20026055 |
| 20 | Printed circuit board | 20025735 |
| 21 | led light guide | 20013352 |
| 26 | Instrumental panel | 20035501 |
| 27 | Knob | 20013055 |
| 31 | Case Assembly | 20026073 |
| 34 | Fixing flange | 20023928 |
| 90 | Fuse | R3478 |
| 100 | Power wiring harness | 20005572 |
| 101 | Cable | R1547 |
| 102 | Low tension cable | 20035502 |

**Table 2**




| POS. | DESCRIPTION | 25 |
|---|---|---|
| 6 | By-pass casing | R10024641 |
| 7 | By-pass valve | R2047 |
| 9 | Heating manifold and cartridge | R10027768 |
| 10 | 3 way valve cartridge | R10025305 |
| 12 | Clip | R10025450 |
| 22 | Safety valve | R10025055 |
| 27 | Heating cock | R1789 |
| 47 | Cover for by-pass assembly | R10024643 |
| 48 | Cock | R10024646 |
| 63 | Pipe | 20025755 |
| 201 | Washer | R5026 |
| 266 | Washer | R5237 |
| 288 | Ring | R6898 |
| 290 | Clip | R2165 |
| 343 | Pump plug | R2216 |
| 432 | Clip | R10024958 |
| 435 | Fitting/union | R10025059 |
| 436 | Clip | R10025062 |
| 440 | Automatic by-pass plug | R10024645 |
| 441 | Clip | R10025063 |
| 442 | O ring | R10025065 |
| 443 | O ring | R10025064 |
| 444 | Washer | R10025066 |

**Table 3**




| POS. | DESCRIPTION | 25 |
|---|---|---|
| 1 | Expansion vessel | 20029826 |
| 2 | Pipe | R10028603 |
| 3 | Pump | R10027571 |
| 4 | Air vent bottle | R10025485 |
| 7 | Pipe | 20025763 |
| 8 | Exchanger group | 20026081 |
| 9 | Pipe | 20025764 |
| 10 | Pipe | 20025744 |
| 17 | Air vent valve | 20019768 |
| 25 | Siphon | 20025733 |
| 27 | Pipe | 20025743 |
| 34 | Degasser kit | 20019888 |
| 60 | Racord | 20025762 |
| 66 | Flexible pipe | R10027545 |
| 71 | Pipe | 20025746 |
| 72 | Vent plug | R10023235 |
| 73 | Cock | R10028431 |
| 200 | Washer | R5023 |
| 288 | Ring | R6898 |
| 290 | Clip | R2165 |
| 302 | Washer | R5025 |
| 370 | O ring | R10023533 |
| 371 | Clip | R10023532 |
| 432 | Clip | R10024958 |
| 619 | Pressure | 20003181 |
| 624 | Clip | R5472 |
| 625 | High limit thermostat | 20005585 |
| 633 | Water detector | 20003819 |
| 668 | Clip | 20019767 |

**Table 4**




| POS. | DESCRIPTION | 25 |
|---|---|---|
| 3 | Fan | 20002995 |
| 4 | Burner assembly | 20026079 |
| 5 | Ignition electrode | 20025737 |
| 12 | Pipe | 20025745 |
| 13 | Gas valve | 20025752 |
| 14 | Gas pipe | 20005553 |
| 15 | 3/4" gas cock | R10020897 |
| 16 | Combustion chamber cover | 20005594 |
| 18 | Plug | 20005550 |
| 27 | Hole cover | 20005586 |
| 33 | Seal ignition electrode | 20025740 |
| 46 | Gas diaphragm | R10029209 |
| 72 | Mixer | 20026083 |
| 77 | Washer | 20025753 |
| 79 | Electrode | 20025738 |
| 92 | Suction pipe | 20025760 |
| 96 | Diaphragme | 20026082 |
| 200 | Washer | R5023 |
| 436 | Clip | R10025062 |
| 613 | Ignition transformer | 20001563 |
| 684 | Washer | 20025747 |

**Table 5**




| POS. | DESCRIPTION | 25 |
|---|---|---|
| 7 | Conveyor | 20026060 |
| 12 | Flue drain connection | R10028421 |
| 20 | Outlet nut | 20026049 |
| 26 | Plug | 20026058 |
| 75 | Flue cllector | 20026056 |
| 370 | O ring | R10023533 |
| 487 | Washer Ø 60 | R10026345 |
| 552 | Washer Ø 60 | R10028426 |
| 637 | Flue sensor | 20007050 |
| 686 | Washer | 20026059 |
| 700 | Combustion cable | 20025736 |

# SECTION 10 - LPG INSTRUCTIONS

## 10.1 RELATED DOCUMENTS

| | | |
|---|---|---|
| **BS 5440** | **PARTS 1 & 2** | **FLUES & VENTILATION REQUIREMENTS** |
| **BS 5449** | **PART 1** | **FORCED CIRCULATION OF HOT WATER SYSTEMS** |
| **BS 5482** | **PART 1** | **DOMESTIC BUTANE & PROPANE GAS BURNERS IN PERMAMENT DWELLINGS** |
| **BS 5546** | | **INSTALLATION OF GAS HOT WATER SUPPLIES FOR DOMESTIC PURPOSES** |
| **BS 6798** | | **INSTALLATION OF BOILERS OF RATED NOT EXCEEDING 60kW** |

### 10.2 TECHNICAL DATA

| **Gas Pressures** | **Mynute 25 A** |
|---|---|
| Inlet pressure | 37.0mbar |
| Heating maximum gas rate (kg/hr) | 1.94 |
| Minimum gas rate (kg/hr) | 0.47 |
| Injector size | 4.4 mm |
| Silencer flange | 29 mm |
| $CO_2$ @ maximum output (%) | 10.0 |
| $CO_2$ @ minimum output (%) | 10.5 |
| CO @ maximum output (ppm) | 170 |
| CO @ minimum output (ppm) | 35 |

## 10.3 CONVERTING THE APPLIANCE GAS TYPE

To convert the appliance to another gas type it is necessary to change the injector and adjust the gas valve ($CO_2$).
- To change the injector see 6.12.1
- To replace the flange on the silencer (only Mynute 29) see 6.15
- To adjust CO2 values see 10.6

## 10.4 GAS SUPPLY

The gas supply must be connected to the appliance by a competent LPG installer and must be of sufficient size to supply the appliance at its maximum output. An existing supply must be checked to ensure that it is of adequate size to deal with the maximum rated input of this and any other appliances that it serves.

## 10.5 GAS SUPPLY INSTALLATION

The entire installation including the meter must be purged and checked for gas tightness.

## 10.6 CHECKING THE $CO_2$ AND ADJUSTING THE GAS VALVE

THE GAS VALVE MUST BE SET-UP OR ADJUSTED WITH THE AID OF A PROPERLY CALIBRATED FLUE GAS ANALYSER.
Isolate the appliance from the electrical supply and remove the appliance casing as described in 4.7.1. Set the flue gas analyser to read $CO_2$ and insert the probe into the flue analysis test point (**Y1-Z1** fig. 33). Restore the electrical supply to the boiler and switch the boiler to the OFF mode.
Have access to the printed circuit board, locate and open the closing plug on the dash board **(L2** fig. 36**)**, locate and press the CO button (see fig. 36 pos. SW1). The appliance will now operate in $CO_2$ mode for approximately 15-minutes.

### 10.6.1 $CO_2$ FUNCTION SETTINGS

Locate the CO button (see 7.3)
Select the main selector switch in position ⏻

| $CO_2$ FUNCTIONS | ACTION ON THE BUTTON | LED STATUS |
|---|---|---|
| combustion analysis mode | press once = burner running at maximum heating | yellow led blinking |
| gas valve maximun setting (*) | press twice = burner running at maximum absolutte | yellow led blinking + red led fixed |
| gas valve minimum setting | press three time = burner running at minimum | yellow led blinking + green led fixed |

(*) this step has not to be used for the system boiler. If you find in this situation press the button once again.

**NOTE**
1 - Any additional pressing of CO button after the third time the burner switched between maximum DHW and minimum.
2 - To restart the $CO_2$ function it is necessary to pass throught the ⏻ position with the main selector switch

### 10.6.2 GAS VALVE MAXIMUM SETTING

Set the CO button at maximum (see 10.3.1), once the maximum is obtained (only yellow led blinking) check that it corresponds with the appropriate $CO_2$ value (Maximum) for the respective appliance. If the $CO_2$ reading is correct, proceed to gas valve minimum setting (10.7.2).
However, if the $CO_2$ reading is incorrect, the maximum gas pressure must be adjusted as follows:
- using a TX 15 key (Torx key), very slowly turn the maximum adjustment screw (see fig. 37) - clockwise to increase, counter clockwise to decrease - until the correct value is displayed on the $CO_2$ analyser (allow time for the analyser to stabilise).

### 10.6.3 GAS VALVE MINIMUM SETTING

Set the CO button at minimum (see 10.3.1), once the minimum is obtained (yellow led blinking + green led fixed) check that it corresponds with the appropriate $CO_2$ value (Minimum) for the respective appliance. If the $CO_2$ reading is correct, proceed to completion (10.7.3).
However, if the $CO_2$ reading is incorrect, the minimum gas pressure must be adjusted as follows:
- locate the minimum adjustment screw (fig. 37), remove the protection plug using a TX 15 key (Torx key)
- using a TX 15 key (Torx key), very slowly turn the minimum adjustment screw (see fig. 37) - clockwise to increase, counter clockwise to decrease - until the correct value is displayed on the $CO_2$ analyser (allow time for the analyser to stabilise).

### 10.6.4 COMPLETION

On completion of the combustion analysis check and/or any gas valve adjustment, refit the plug **(L2** j**)** and move the mode selector to the position. Remove the test probe from the test point and refit the sealing screw/s and/or cap.

**IMPORTANT**
**A GAS TIGHTNESS CHECK MUST BE CARRIED OUT IF ANY GAS CARRYING COMPONENTS HAVE BEEN REMOVED, REPLACED OR DISTURBED.**
**ATTENTION**
Gas type and appliance output **must be set** according to the specific appliance specification.
Vokèra accepts no responsibility if the gas type and/or appliance output is not correctly adjusted according to the respective appliance specification as detailed on the appliance data badge.

# GAS BOILER SYSTEM COMMISSIONING CHECKLIST

This Commissioning Checklist is to be completed in full by the competent person who commissioned the boiler as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.

Failure to install and commission this equipment to the manufacturer's instructions may invalidate the warranty but does not affect statutory rights.

Customer Name _____ Telephone Number _____

Address _____

Boiler Make and Model _____

Boiler Serial Number | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Commissioned by (print name) _____ CORGI ID Number _____

Company Name _____ Telephone Number _____

Company Address _____

_____ Commissioning Date _____

**To be completed by the customer on receipt of a Building Regulations Compliance Certificate * :**

Building Regulations Notification Number (if applicable) _____

## CONTROLS **Tick the appropriate boxes**

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Time and Temperature Control to Heating | Room Thermostat and Programmer/Timer | ☐ | Programmable Room Thermostat | ☐ | Load/Weather Compensation | ☐ | Optimum Start Control ☐ |
| Time and Temperature Control to Hot Water | | | Cylinder Thermostat and Programmer/Timer | ☐ | Combination Boiler | ☐ | |
| Heating Zone Valves | | | | | Fitted ☐ | Not Required ☐ | |
| Hot Water Zone Valves | | | | | Fitted ☐ | Not Required ☐ | |
| Thermostatic Radiator Valves | | | | | Fitted ☐ | Not Required ☐ | |
| Automatic Bypass to System | | | | | Fitted ☐ | Not Required ☐ | |
| Boiler Interlock | | | | | | Provided ☐ | |

## ALL SYSTEMS

The system has been flushed and cleaned in accordance with BS7593 and boiler manufacturer's instructions Yes ☐

What system cleaner was used? _____

What inhibitor was used? Quantity _____ litres

## CENTRAL HEATING MODE **Measure and Record:**

| | | | | | |
|---|---|---|---|---|---|
| Gas Rate | _____ $m^3/hr$ | OR | | _____ $ft^3/hr$ | |
| Burner Operating Pressure (if applicable) | _____ mbar | OR | Gas Inlet Pressure | _____ mbar | |
| Central Heating Flow Temperature | | | | _____ °C | |
| Central Heating Return Temperature | | | | _____ °C | |

## COMBINATION BOILERS ONLY

Is the installation in a hard water area (above 200ppm)? Yes ☐ No ☐

If yes, has a water scale reducer been fitted? Yes ☐ No ☐

What type of scale reducer has been fitted? _____

**DOMESTIC HOT WATER MODE Measure and Record:**

| | | | | | |
|---|---|---|---|---|---|
| Gas Rate | _____ $m^3/hr$ | OR | | _____ $ft^3/hr$ | |
| Burner Operating Pressure (at maximum rate) | _____ mbar | OR | Gas Inlet Pressure (at maximum rate) | _____ mbar | |
| Cold Water Inlet Temperature | | | | _____ °C | |
| Hot water has been checked at all outlets | Yes ☐ | | Temperature | _____ °C | |
| Water Flow Rate | | | | _____ l/min | |

## CONDENSING BOILERS ONLY

The condensate drain has been installed in accordance with the manufacturer's instructions and/or BS5546/BS6798 Yes ☐

## ALL INSTALLATIONS

If required by the manufacturer, record the following $CO_2$ _____ % OR CO _____ ppm OR $CO/CO_2$ Ratio _____

The heating and hot water system complies with the appropriate Building Regulations Yes ☐

The boiler and associated products have been installed and commissioned in accordance with the manufacturer's instructions Yes ☐

The operation of the boiler and system controls have been demonstrated to and understood by the customer Yes ☐

The manufacturer's literature, including Benchmark Checklist and Service Record, has been explained and left with the customer Yes ☐

Commi ssioning Engineer's Signature _____

Customer's Signature _____

(To confirm satisfactory demonstration and receipt of manufacturer's literature)

*All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.

benchmark COLLECTIVE MARK
THE MARK OF QUALITY FOR THE INSTALLATION, COMMISSIONING AND SERVICING OF DOMESTIC HEATING AND HOT WATER SYSTEMS

©Heating and Hotwater Industry Council (HHIC)

www.centralheating.co.uk

# SERVICE RECORD

It is recommended that your heating system is serviced regularly and that the appropriate Service Record is completed.

**Service Provider**
Before completing the appropriate Service Record below, please ensure you have carried out the service as described in the manufacturer's instructions.

Always use the manufacturer's specified spare part when replacing controls.

**SERVICE 1** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 2** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 3** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 4** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 5** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 6** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 7** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 8** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 9** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

**SERVICE 10** Date

Energy Efficiency Checklist completed? Yes ☐ No ☐

Engineer Name

Company Name

Telephone Number

CORGI ID Number

Comments

Signature

Vokèra
heating for life

Cod. 20030102 - 02/11 - Ed. 0

**Registered address:**
Vokèra Ltd
Borderlake House
Unit 7 Riverside Industrial Estate
London Colney
Herts AL2 1HG

**enquiries@vokera.co.uk**

**www.vokera.co.uk**
**www.vokera.ie**

***Sales, General Enquires***
**T** 0844 391 0999
**F** 0844 391 0998

Vokèra Ireland
West Court, Callan
Co Kilkenny
**T** 056 7755057
**F** 056 7755060

Vokèra Limited reserve the right to change specification without prior notice
Consumers statutory rights are not affected.

A Riello Group Company.
Company Reg No: 1047779